

May 31, 2012

ReVeal MPX Software Updates

Software version 1.6.8

Release Scope:

General Availability

New features and improvements:

1. Support VoIP option control

Known issues or limitations:

a. Nothing significant to report

Software version 1.6.6

Release Scope:

General Availability

New features and improvements:

- 1. Fixed the problem with error being introduced when stopping RFC2544 Test
- 2. Added Mbps selection in RFC2544 Test profile
- 3. Support ARP and ARP Gateway functions
- 4. Support the following new test patterns:
 - a) Special PRBS 2E31
 - b) Special PRBS 2E23
 - c) Special PRBS 2E15
 - d) Special PRBS 2E11
 - e) PRBS All One's
 - f) PRBS All Zeor's
- 5. Support user defined Ethernet Type setting
- 6. Improved connection menu to allow user to enter the IP address of a MPX100 in additional to device discovery.

Known issues or limitations:

a. Nothing significant to report

Software version 1.6.5

Release Scope:

General Availability

New features and improvements:

1. Fixed issue relating to Throughput Test

Known issues or limitations:

a. Nothing significant to report

August 18, 2011

October 12, 2010

VEX

npleted

Software Release Notes

ReVeal MPX

Release Scope:

General Availability

New features and improvements:

- 1. Enable the Start button and the Save buttons when RFC2544 Test is completed.
- 2. Support Date Sync
- 3. Corrected Add Option issue
- 4. Correct Schedule Test issue

Known issues or limitations:

a. Nothing significant to report

Software version 1.6.3

Release Scope:

General Availability

New features and improvements:

1. Added VLAN setting in IP configuration

Known issues or limitations:

a. Nothing significant to report

Software version 1.5.2

Release Scope:

General Availability

New features and improvements:

- 1. Added port settings to VoIP profile
- 2. Fixed not starting loopback problem
- 3. Fixed issues on Schedule Test function
- 4. Fixed issues on History View function

Known issues or limitations:

a. Nothing significant to report

Software version 1.5.1

Release Scope:

General Availability

New features and improvements:

1. Fixed port setting problem in loopback profile

Known issues or limitations:

a. Nothing significant to report

May 27, 2010

December 10, 2008

September 6, 2010



ReVeal MPX

Software Release Notes

Software version 1.5.0

Release Scope:

General Availability

New features and improvements:

- 1. New User Interface format
- 2. Support VoIP Test and Schedule Test functions

Known issues or limitations:

a. Nothing significant to report

December 3, 2008



References

Upgrading the ReVeal MPX software

Once you have obtained the compressed software file. Extract the compressed file to the local drive of the PC, where the ReVeal MPX will be installed. Install the software only after extracting the files to avoid running into error (error code 2689).

It is recommended to manually uninstall the existing version from the Control Panel if the privilege setting used in the previous installation is not known. Otherwise, the installer package will not completely clean up the previous version. This will result the Help > About ReVeal MPX Lite still shows the old version after the upgrade. The old and the new versions will also be listed in the Control Panel program list.

On PC running Windows 7, right click the Setup.exe file and select Run as administrator to start the software installation process for non-Administrator login.

© 2012 VeEX Inc. All rights reserved.

VeEX, VePAL, ReVeal, and the V logos are trademarks or registered trademarks of VeEX Incorporated, or one of its affiliates. All other trademarks or registered trademarks are the property of their respective owners. Some features listed in this document require software options that may require paid activation or license, and may or may not be available in all products. VeEX Inc., reserves the right to change, without notice, product offerings or specifications.