

Real-Time / Remote / Offline SS7 Protocol Analyzer

USER GUIDE

Document No-XX120-7.10.24-03

November 2013

GL Communications Inc.
818 West Diamond Avenue - Third Floor
Gaithersburg, MD 20878
Voice 301-670-4784
Fax 301-670-9187
Web page: <http://www.gl.com/>
E-mail: gl-info@gl.com

(Intentional Blank Page)

TABLE OF CONTENTS

Application I - Real-time Protocol Analysis	1
Section 1.0 Overview	1
1.1 Introduction	1
1.2 Main features	2
1.3 Offline / Remote Protocol Analyzer	3
1.4 Supported Protocols (SS7 ITU/ ANSI/ETSI/CHINA/UK)	4
Section 2.0 Getting Started	5
2.1 Installation	5
2.2 Invoking Real-time Protocol Analyzer	5
2.3 User Interface	6
Section 3.0 File Menu Options	7
3.1 Start Real-time	7
3.2 Stop/Pause	8
3.3 Opening Trace for Offline Analysis	9
3.4 Close Trace	10
3.5 Save As and Close	10
3.6 Save As	11
3.7 Export Details	12
3.8 Export Summary	12
Section 4.0 View Menu Options	13
4.1 Define Views to Display	14
4.2 Summary View	14
4.2.1 Setting a Relative Time	14
4.2.2 Summary Column Selection	16
4.2.3 Column Resizing and Reordering	17
4.2.4 Repositioning Summary View	18
4.2.5 Summary Colors	19
4.2.6 Define Views	19
4.3 Detail View - Selecting Individual Frame	20
4.3.1 Layer Copy/Show/Hide Options	22
4.4 Hex Dump View	23
4.5 Statistics View	23
4.6 Protocol Standard	23
4.7 User/Network Side Specification	24
4.8 Time Displays	25
4.8.1 Relative Time	25
4.8.2 System Time	25
4.8.3 Date and Time	25
4.8.4 Difference Time	25
4.9 Latest	26
4.10 View Filtering Criteria	26
4.10.1 Setting Filtering Criteria	27
4.10.2 Activate Filter	28
4.10.3 Deactivating Filter	29
4.10.4 Example - View Filter	29
4.11 Searching for Specific Frames	30
4.12 Forward Search & Backward Search	31
4.12.1 Searching Towards the End of the Trace (Forward Search)	31
4.12.2 Searching Towards the Beginning of the Trace (Backward Search)	31
4.12.3 Example - Search for particular frames	32
4.13 Display Trace File Name	33
4.14 Default Summary Columns	33
Section 5.0 Capture Menu Features	35

5.1	Periodic trace saving options	35
5.2	Setting Capturing Options	37
5.2.1	In Memory for High Traffic Capture Rate	37
5.2.2	Circular Capture Buffer	37
5.3	Stream /Interface (Port) Selection.....	38
5.3.1	Port and Timeslots Selection.....	39
5.3.2	User/ Network Side Specification	39
5.3.3	Bit Inversion.....	39
5.3.4	Octet Bit Reversion	40
5.3.5	HDLC FCS	40
5.3.6	Data Transmission Rate	40
5.4	Setting Capture Filter using Real-time Analyzer.....	42
5.5	Capture Physical Layer Alarms	43
5.6	GUI and Protocol Options	43
Section 6.0	Statistics.....	45
6.1	Steps to Display Statistics	46
6.1.1	Selecting Field Names (Step 1)	47
6.1.2	Defining Use Type (UT) and Statistics Type (Step 2).....	49
6.1.3	Update Selected Statistics Information List (Step 3)	50
6.1.4	Example 1 - Statistics with a Key UT	51
6.1.5	Example 2 - Statistics with a Total and a Key	52
6.1.6	Example 3 - Statistics Total and Field UT	54
6.1.7	Ranges, Wildcards And Enumerated Value Sets.....	55
6.1.8	Modifying and/or removing configured statistics.....	56
6.2	Opening and Closing Statistics View.....	56
6.3	Loading Statistics	57
6.4	Load and Edit Statistics.....	57
6.5	Save Statistics	57
6.6	Export Statistics.....	58
Section 7.0	Call Detail Records.....	59
7.1	Build Call Detail Record	59
7.2	Select Call Detail Columns to Display	60
7.3	Active Calls Only	60
7.4	Open Call Detail Record	61
7.5	Call Detail View	62
7.5.1	Active and Completed Calls	64
7.5.2	Call Duration	64
7.5.3	Find CDR	65
7.6	Display Selected Call Summary	66
7.7	Display Entire Summary.....	66
7.8	Closing Call Detail Record.....	66
7.9	Export Trace File	67
Section 8.0	Protocol Analyzer Configuration	69
8.1	Analyzer GUI Options and Protocol Configurations	69
8.1.1	Selecting summary columns to display	70
8.1.2	Menu Checked Options	71
8.1.3	Protocol Standard Selection.....	71
8.1.4	Network/User side Selection	72
8.1.5	Time Format.....	72
8.1.6	View Filter.....	72
8.1.7	View Search	72
8.1.8	TCP Connection Options.....	73
8.1.9	Periodic trace saving options	73
8.1.10	Startup Options	74
8.1.10.1	Executing Tasks on Analyzer Startup	75

8.1.11 Data Link Groups (DLG)	79
8.1.12 View Font Size	80
8.1.13 INI Decode Options.....	81
8.1.14 Define Summary Columns	84
8.2 Capture Options	87
Section 9.0 Status Indicators	89
9.1 Status and Progress Indicator	89
9.2 Trace File Name	89
9.3 Filtered and Total Frame Count	89
9.4 Error Counters	89
Application II - Remote / Offline Analyzer	91
Section 1.0 Installation	91
1.1 Installation Procedure	91
1.2 Dongle License Installation	91
1.3 Software Installation (Windows® XP).....	92
Section 2.0 Getting Started with Remote Protocol Analyzer	95
2.1 Invoking Remote Protocol Analyzer	95
2.1.1 Remote Analysis.....	96
2.2 Stream /Interface Selection	97
2.3 Setting Capture Filter	100
2.4 Start Real-time Analysis	100
Section 3.0 Getting Started with Offline Protocol Analyzer.....	101
Appendix A - Glossary	103
Appendix B - Configuring SS7Prot.ini file	105

(Intentional Blank Page)

TABLE OF FIGURES

Figure 1: SS7 Protocol Analysis	1
Figure 2: SS7 Network	2
Figure 3: SS7 Protocol Stack for TDM Low- or High-Speed Links	4
Figure 4: Invoking the Protocol Analysis	5
Figure 5: Summary, Detail, Hex dump, Statistics Views	6
Figure 6: File Menu Options.....	7
Figure 7: Saving the trace file.....	7
Figure 8: Real-time Analysis.....	8
Figure 9: Open a Trace from a File for Off-line Analysis.....	9
Figure 10: Offline Analysis	9
Figure 11: Open a Trace File from Command Prompt.....	10
Figure 12: Save Trace As File Name and Close.....	10
Figure 13: Save As.....	11
Figure 14: Exporting Trace to an ASCII File	12
Figure 15: Exporting Summary to an ASCII File	12
Figure 16: View Menu Options	13
Figure 17: Define Views to Display	14
Figure 18: Set Relative Time	15
Figure 19: Select Columns to Display	16
Figure 20: Column Resizing and Reordering	17
Figure 21: Repositioning the Summary View.....	18
Figure 22: Set Summary Colors	19
Figure 23: Detail View of Individual Frame	20
Figure 24: SS7 Over IP.....	21
Figure 25: MTP2 Layer Coded in HSL.....	21
Figure 26: Selecting Show Layer Option.....	22
Figure 27: Copying Detail View Information.....	22
Figure 28: Select Protocol Standard	23
Figure 29: User/Network Side Specifications.....	24
Figure 30: Time Displays	25
Figure 31: Auto Screen Refresh During Real-time Analysis	26
Figure 32: Setting Filtering Criteria	27
Figure 33: Activating Filter	28
Figure 34: Deactivating Filter	29
Figure 35: Example - Filter Option to filter Error Frames Only.....	29
Figure 36: Setting Search Criteria	30
Figure 37: Searching Forward or Backward Options.....	31
Figure 38: Example - Search option to search for frames of specific length.....	32
Figure 39: Trace File Name	33
Figure 40: Default Summary Columns	33
Figure 41: Periodic File Saving Specifications.....	35
Figure 42: Capturing Options.....	37
Various options are available for saving trace file, refer to Periodic Trace Saving Options for details.	37
Figure 43: Stream/Interface Selection	38
Figure 44: User/ Network Side Specification	39
Figure 45: Specifying Bit Inversion Option.....	39
Figure 46: Specifying Octet Bit Reversion Option	40
Figure 47: Specifying FCS Value	40
Figure 48: Specifying Channel Selections	40
Figure 49: Capture Filter	42
Figure 50: Capture Filter – Select Protocol Value.....	43
Figure 51: Protocol Analysis with Statistics View	45
Figure 52: Statistics Definition Dialogue.....	46
Figure 53: Selecting Field Names	47
Figure 54: Field Types	48
Figure 55: Selected Statistics Information List	50
Figure 56: Define Statistics with a Key UT	51
Figure 57: Statistics with a Key UT.....	52
Figure 58: Select Statistics with a Total and a Key	53
Figure 59: Statistics with a Total and a Key	54
Figure 60 : Range List for Numeric Fields	55
Figure 61: Wildcards for String fields.....	55
Figure 62: Specifying Value Sets.....	56

Figure 63: Modify/Remove some or all statistics	56
Figure 64: Opening and Closing Statistics View.....	56
Figure 65: Loading Statistics	57
Figure 66: Save Statistics as Filename	57
Figure 67: Export Statistics as Filename	58
Figure 68: Call Detail Records View.....	59
Figure 69: Build Call Detail Record.....	59
Figure 70: Select Call Trace Columns to Display	60
Figure 71: Open Call Detailed Record	61
Figure 72: Warning Message	61
Figure 73: Call ID Status for SS7	62
Figure 74: Active, Completes Calls, and Call Duration.....	64
Figure 75: Find CDR.....	65
Figure 76: Specify CDR criteria.....	66
Figure 77: Close Call Detailed Record	66
Figure 78: Export Trace File	67
Figure 79: Protocol and GUI option	69
Figure 80: Save Configuration Options to File.....	70
Figure 81: Load Configuration Options.....	70
Figure 82: Menu Checked Option	71
Figure 83: Protocol Standard Selection	71
Figure 84: Network/User side Selection	72
Figure 85: Time Format.....	72
Figure 86: TCP Connection Options	73
Figure 87: Startup Options	74
Figure 88: Selection of Summary Columns.....	75
Figure 89: Selection of Startup Options	76
Figure 90: Saving Configuration File.....	77
Figure 91: Loading Configuration File	78
Figure 92: Data Link Groups	79
Figure 93: View Font Size	80
Figure 94: INI Decode Option.....	81
Figure 95: .INI File	82
Figure 96: Warning Message	83
Figure 97: Define Summary Column	84
Figure 98: Popup Message	85
Figure 99: Adding the Summary Field to Display Summary Column	86
Figure 100: Added summary field	87
Figure 101: Analyzer Status Indicators	89
Figure 102: Dongle License Installation	91
Figure 103: Welcome Screen.....	92
Figure 104: License Agreement	92
Figure 105: Choose Destination Folder	93
Figure 106: Select Program Folder.....	93
Figure 107: Setup Status.....	94
Figure 108: Protocol Analyzer Installation Completed	94
Figure 109: License Error Message.....	94
Figure 110: Invoking the Remote Protocol Analysis Application.....	95
Figure 111: WCS Server Connect.....	96
Figure 112: Specifying timeslot Selection for a Remote Analyzer	97
Figure 113: Info of IP Addr/Cards	99
Figure 114: Capture Filter using Remote Analyzer.....	100
Figure 115: Open a Trace from a File for Off-line Analysis.....	101
Figure 116 : Offline Analysis	101
Figure 117: INI Decode Option for SS7 Analyzer	105
Figure 118 : Decode of INAP CS1 Layer	107
Figure 119 : Decode of INAP CS2 ITU Layer	108
Figure 120 : Decode of INAP CS2 ETSI Layer	109
Figure 121 : Selection of Default Summary Fields for Surveillance (TCP/IP)	110
Figure 122 : CNAM Call Detail Records	111
Figure 123 : MTP2 Decoded in High Speed Link	112

Application I - Real-time Protocol Analysis

Section 1.0 Overview

1.1 Introduction

SS7 (Signaling System 7) separates the information required to set up and manage telephone calls in the Public Switched Telephone Network (PSTN) onto a separate packet switched network (Signaling Network). It uses Message Signal Units (MSUs), Link Status Signal Units (LSSUs), and Fill-In Signal Units (FISUs) as signal units. The main protocols include MTP (Message Transfer Part – Level 1 to 3), SCCP (Signaling Connection Control Part), and ISUP (ISDN User Part).

As a result of introducing new IN services there is a demand for increase in SS7 network capacity. High Speed Link (HSL) is defined to meet this requirement which uses entire or fractional E1 bandwidth instead of just 64kbit/s to carry SS7 signaling. The HSL technology can be implemented either using unchannelized HDLC (over MTP2), ATM (ATM layers replace MTP1 and 2), or SIGTRAN.

GL's **SS7 Analyzer** supports decoding different SS7 layers like MTP2, MTP3, ISUP, TUP, SCCP, INAP, IUP, BICC, BISUP, BTUP, and many application layer protocols from GSM/GPRS network like MAP, CAMEL (CAP), and so on.

Additionally, the SS7 Analyzer supports decoding of high-speed 1.544- or 2.0-Mbps unchannelized HDLC high-speed signaling links [HSL]) over T1/E1.

Both real-time and off-line analysis present information in four layers:

- Raw HDLC Frame data as a hexadecimal and ASCII octet dump
- MTP2 and MTP3 information
- ISUP, TUP, SCCP, BICC, INAP, MAP, BTUP, etc. information




Figure 1: SS7 Protocol Analysis

GL Communications supports the following types of SS7 analyzers:

- Real-time SS7 Analyzer (Pre-requisites: GL's field proven E1 or T1 internal cards or USB Laptop E1 or T1 external units, required licenses and Windows XP (or higher) Operating System).
- Remote / Offline SS7 Analyzers (Pre-requisites: Hardware dongle and Windows XP (or higher) Operating System).




Figure 2: SS7 Network

1.2 Main features

<p>Display Features</p>	<ul style="list-style-type: none"> • Displays Summary, Detail, Hex-Dump, Statistics, and Call Detail Views. • Summary View displays MTP2, MTP3 information and SS7 Message types, Called and Calling number, SCCP message type, SSN, INAP information, IUP information, BICC message type, and etc in a tabular format. • Detailed View <ul style="list-style-type: none"> ➢ Displays decodes of user-selected frames from the Summary View ➢ Provides options to display or hide the required protocol layers ➢ Contents of this view can also be copied to clipboard. • Hex dump View displays the frame information in HEX and ASCII format, the contents of this view can also be copied to clipboard. • Statistics View displays call and MSU statistics at any link or entire link set. • Any protocol field can be added to the summary view, filtering, and search features providing users more flexibility to monitor required protocol fields • Call trace isolates call specific information i.e. status of each call (i.e. active/completed), duration of completed call, OPC, DPC, CIC, Called and Calling Party Numbers, and more.
<p>Supported Protocols</p>	<ul style="list-style-type: none"> • SS7 ITU, SS7 ANSI, SS7 ETSI, SS7 CHINA, and SS7 UK • Supports analysis of GSM/UMTS MAP interfaces supported are <ul style="list-style-type: none"> ➢ B (Interface b/w the MSC and its associated VLR) ➢ C (Interface b/w the HLR and the MSC) ➢ D (Interface b/w the HLR and the VLR) ➢ E (Interface b/w MSCs) ➢ F (Interface b/w MSC and EIR) ➢ H (Interface between HLR and AuC) ➢ J (Interface b/w the HLR and the gsmSCF) • Supports analysis of SSP-STP (A link, E link), STP-STP (B link, C link), & SSP-SSP (F link) interfaces.
<p>Filtering and Search</p>	<ul style="list-style-type: none"> • Advanced filtering and search based on any user selected protocol fields
<p>Capturing Streams</p>	<ul style="list-style-type: none"> • Streams can be captured on the selected time slots (contiguous or non-contiguous), sub-channels or full bandwidth.

	<ul style="list-style-type: none"> • Frames can be transmitted/captured in either 64 kbps, 56 kbps, n x 64 kbps, or n x 56 kbps data channels (hyper-channels) • Capable of decoding many important protocols from GSM/GPRS network i.e. MAP, CAP. • Supports decoding of frames with FCS of 16 bits and 32 bits, or none.
Export Options	<ul style="list-style-type: none"> • Exports Summary View information to a comma delimited file for subsequent import into a database or spreadsheet. • Capability to export detailed decode information to an ASCII file
Record/Playback	<ul style="list-style-type: none"> • Recorded trace files can be played back using HDLC playback application.
Remote Monitoring	<ul style="list-style-type: none"> • Remote monitoring capability using GL's Network Surveillance System.
Call Detail Record	<ul style="list-style-type: none"> • Call details recording feature includes data link groups that help in defining the direction of the calls in a given network and form logical groups comprised of unidirectional (either 'Forward' or 'Backward') data links.
Additional Features	<ul style="list-style-type: none"> • Trace files for analysis can be loaded through simple command-line arguments. • Multiple trace files can be loaded simultaneously with different GUI instances for offline analysis. • The following variations are accommodated in the software: inverted or non-inverted data, byte reversal or non-reversal. • Multiple streams of SS7 traffic on various T1/E1 channels can be simultaneously decoded with different GUI instances. • HDLC (according to Q.921) based SS7 frames are parsed based on ANSI and ITU standards. • Ability to configure the .ini file for custom decoding options such as SSN value of INAP, MAP, CAP, TCAP, and IS41, and more.

1.3 Offline / Remote Protocol Analyzer

GL Communications offers the Remote Access (client/server) functionality to the T1/E1 products. This functionality allows analyzer operations to be remotely controlled by one or more clients over a LAN, WAN, or Internet. Remote client supports Microsoft® Windows® operating systems and includes a DLL component, which may be accessed through a GUI. GL's offline/remote protocol analyzers are available as optional software. Functionally, they are similar to real-time protocol analyzers that are integrated with T1E1 Analyzers.

With Remote Protocol Analyzer applications, users can perform real-time as well as offline protocol analysis from any remote-site. However, with Offline Protocol Analyzers, user can decode the pre-captured files from any remote-site. For details on Remote SS7 Analyzer, refer to section [Remote SS7 Analyzer](#)

Pre-requisites of the remote functionality are:

At the site of monitoring

- Dual Capture T1 E1 Cards or USB Based T1 E1 Hardware
- T1 E1 Server software with HDLC capture software

At the client location

- Appropriate GUI based "Remote Protocol Analyzer" at such as ISDN, SS7, and others

The RPA functionality permits:

- unattended and 24/7 operation
- remote accessibility for difficult connection situations
- remote non-intrusive operation
- remote detail diagnostic capability

Main Features

- Client side consists of a PC with Ethernet connectivity and GUI Remote Protocol Analysis software – no special T1 or E1 hardware is required.
- Multiple T1/E1 servers may be simultaneously connected to a single remote client using a single GUI.

- Multiple remote clients may access a single T1/E1 server. Also, the T1/E1 server is fully functional while being accessed as a server. Thus, a user may perform T1/E1 operations locally on the server while a client is accessing the same server, in real time.
- Supports real-time and offline analysis at the remote client location.
- Remote analyzers support capturing of encapsulated protocols and long frames.
- Common filtering criteria can be set for T1/E1 cards located on multiple servers.

1.4 Supported Protocols (SS7 ITU/ ANSI/ETSI/CHINA/UK)




Figure 3: SS7 Protocol Stack for TDM Low- or High-Speed Links

- MTP2: Q.704, ITU-T Blue Book / ANSI T1.111-1996
- MTP3: MTP2: Q.703, ITU-T Blue Book / ANSI T1.111-1996
- SCCP: Q.713, CCITT (ITU-T) Blue Book / ANSI T1.112-1996
- CNAM: GR-1188-CORE Issue 3, April 2009
- MAP (MAP R99 and MAP R4):
 - 3GPP TS 09.02 V7.14.0 (2003-09)
 - 3GPP TS 29.002 V4.18.0 (2007-09)
- INAP CS1 (Capability Set 1): Q1218 (10 / 95) and ETSI ETS 300 374 1, Sept, 1994
- INAP CS2 (Capability Set 2)
 - INAP CS2: ITU recommendation Q.1228
 - INAP CS2 (ETSI): EN 301 140-1 Specification
- Note: INAP decoding for ITU and ETSI are different in case of INAP CS2, but they are same in INAP CS1.
- CAMEL (Version 6 and Version 3):
 - 3GPP TS 29.078 V3.15.0 (2003-03)
 - 3GPP TS 29.078 6.3.0 (2004-09)
- ISUP: Q.763, CCITT (ITU-T) Blue Book / ANSI T1.113-1995 / EN 300 356 -1 V3.2.2 (1998-08) Part I and Q763 / ND1007:2007/01 TSG/SPEC/007
- TUP: Q.723, CCITT (ITU-T) Blue Book
- Test & Network Mgmt Messages:- Q.703, Q.704, ITU-T Blue Book / ANSI T1.111-1996
- TCAP (IS 41): Q.773, CCITT (ITU-T) Blue Book / ANSI T1.114 -1996/ TIA/EIA/IS-41.5-C
- Interconnect User Part (IUP) / BTUP - equivalent to ISUP in SS7 UK standard.
 - ND1006:2005/02 PNO-ISC/SPEC/006
 - ND1104:2004/11 PNO-ISC/INFO/004 - Proprietary Extensions To C7 Interconnect User Part (IUP)
- BICC: T-REC-Q.1902.1-200107, T-REC-Q.1902.2-200107, T-REC-Q.1902.3-200107, T-REC-Q.1902.4-200107 (pl-080r1)
- BISUP: Q.2763, Q.2931, Q.2933, Amendment 2 of Q.2931, Q.2941.1 etc

Section 2.0 Getting Started

2.1 Installation

The Real-time protocol analyzer is available as optional software with the GL's T1/E1 analyzer. Users require a GL's license to integrate the protocol analyzer with already existing T1/E1 Analyzer. Once the license has been installed properly using license installer, the application can be invoked as explained in the following section.

For installing offline and remote protocol analyzers, first install T1 E1 hardware, server software, and protocol capture software. At the remote site, install the GUI based Offline/Remote protocol analyzer application. For more details on installation of offline protocol analyzer, refer to section [Offline / Remote Analyzer Installation](#). For details on installing T1E1 Analyzer, refer to [T1E1 Installation User Manual](#) for the required Windows® operating system.

2.2 Invoking Real-time Protocol Analyzer

Double-click the T1/E1 Analyzer icon located on the desktop to invoke the application. The T1/E1 Analyzer executable is located in the directory `Program Files\GL Communications Inc`. From the main window of T1/E1 Analyzer, click **Special Applications > Protocol Analysis** and select the required protocol analyzer as shown below:




Figure 4: Invoking the Protocol Analysis

2.3 User Interface

The user interface comprises of main menu, toolbar, sub menu toolbar and different views, which includes **Summary View** at the top, followed by the **Detail**, **Hex Dump**, **Statistics**, and optional **Call Detail View** at the bottom as shown in the figure below:




Figure 5: Summary, Detail, Hex dump, Statistics Views

The main menu tool bar comprises of File, View, Capture, Statistics, Database, Call Detail Records, Configure, and Help menu. The main menu and the tool bar are used to select an operation to perform. The status fields at the bottom of the window display miscellaneous status information. Most of the operations can be performed either using the main menu or the corresponding tool button.

The features under these menus are explained in detail later, in this document.

The protocol analyzer opens with Summary, Detail and Hex Dump as default panes. Statistics and Call Detail are optional panes, which can be viewed if required. User have the options to set the required panes by using **Views > Define Views**. The splitter separating the summary, detail and hex dump views can be adjusted according to user preferences. The summary view columns can be resized and reordered.

- **Summary View** displays various columns such as Dev#, Frame Number, Time, Length, Error, Src/dest IP addresses, Frame Type, and so on.
- User selects a frame in the Summary View to get the detail protocol field information in the **Detail View**.
- Raw data for the selected Summary View frame is displayed in the **Hex-dump View** in HEX and ASCII formats.

Section 3.0 File Menu Options

The File menu includes following submenus -

- Start Real-time
- Stop
- Off-line
- Close
- Save As
- Save As and Close
- Export Details
- Export Summary




Figure 6: File Menu Options

3.1 Start Real-time

Users can capture and analyze frames in real-time and record all or filtered traffic into a trace file. The recorded trace file can then be analyzed offline and exported to ASCII file, or printed.



Note:

This feature is applicable to real time analyzer only.

To start the real-time analysis:

- Click **File > Start Real-time**
- Click **Start Real-time**  from the toolbar

After you click the **Start Real-time** button, a warning message for overwriting the temporary trace file is displayed. If you want to overwrite click **Yes**, else, click **No** and save it as a new file in the desired location. This new file replaces the default specified in the capturing options dialog.




Figure 7: Saving the trace file

The real-time analysis is used to capture data on one or multiple T1/E1 lines on the specified timeslots simultaneously during transmission. The captured data is always stored in a temporary file. Before capturing is started, the capturing options and timeslots must be set. These settings are saved in the Windows® registry and can be reused between analyzer sessions.

The Real-time analysis procedure entails the following steps to be performed:

- 1) Specify the file on which the transmission should be captured using the capture file options (refer to section [Setting Capturing Options](#) for further details).
- 2) Specify timeslots and other Stream/Interface selections using **Capture > Stream Interface Selection** (refer to section [Stream / Interface \(Port\) Selection](#) for further details).
- 3) Specify the way in which the transmission should be captured to additional trace files using the Periodic Trace Saving option (refer to section [Periodic Trace Saving Options](#)).
- 4) Start/Suspend the Real-time analysis using the Start/Pause menu options available under the file menu (Refer to sections [Start Real-time](#) and [Stop/Pause](#) for further details).
- 5) Export captured information from Summary and Detail Views to files as explained in sections [Export Details](#) and [Export Summary](#).
- 6) Save current trace with a new file name (Refer to [Save As and Close](#) for further details).

The following image shows the real time analysis:

The screenshot displays the SS7 Protocol Analysis SS7 ITU software interface. The top window shows a table of captured frames with columns: Len, Error, BSN, BIB, FSN, FIB, Statu..., SLC, DPC, DPC, SCCP Message Type, and SSN. Below the table, the 'Card2 TimeSlots=1-6 Frame=15 at 00:00:00.037291 OK Len=22' is shown. The 'HDLC Frame Data + FCS' section details the MTP2 and MTP3 layers. The MTP2 layer fields include BSN, BIB, FSN, FIB, and LI. The MTP3 layer fields include Service Indicator, Priority Code, and Sub-service field. The 'Hex Dump of the Frame Data' section shows the raw hexadecimal data: 01 02 03 05 14 80 02 00 00 0A 2F 02 07 05 02 42 11 22 33 00 1C C2. The status bar at the bottom indicates 'Running. Utilization 19.67%', 'C:\Temp.Hdl', and 'Captured 5731 frames'.

Len	Error	BSN	BIB	FSN	FIB	Statu...	SLC	DPC	DPC	SCCP Message Type	SSN
22		1	0	2	0		0	0.24	0.12		
14		1	0	2	0		0	0.24	0.12		
13		1	0	2	0		0	0.24	0.12		
40		1	0	2	0		0	0.24	0.12		
26		1	0	2	0		0	0.24	0.12		
40		1	0	2	0		0	0.24	0.12		
38		1	0	2	0		0	0.24	0.12		
22		1	0	2	0		0	0.24	0.12		

```

Card2 TimeSlots=1-6 Frame=15 at 00:00:00.037291 OK Len=22
HDLC Frame Data + FCS
===== MTP2 Layer =====
BSN = .0000001 (1)
BIB = 0..... (0)
FSN = .0000010 (2)
FIB = 0..... (0)
LI = ..000011 MSU Format
===== MTP3 Layer =====
Service Indicator = ....0101 ISDN User Part
Priority Code = ..00.... Priority Code 0
Sub-service field = 00..... International network

Hex Dump of the Frame Data
+-----+-----+-----+-----+-----+-----+-----+-----+
01 02 03 05 14 80 02 00 00 0A 2F 02 07 05 02 42          |  |  |  |  |  |  |  |  |
11 22 33 00 1C C2                                         "3  A  /  B
  
```

Running. Utilization 19.67% C:\Temp.Hdl Captured 5731 frames

Figure 8: Real-time Analysis

3.2 Stop/Pause



Note:

This feature is applicable to real time analyzer only.

To suspend real-time capturing, follow the steps given below.

- Click **File > Stop/Pause** or
- Click **Stop**  from the toolbar

3.3 Opening Trace for Offline Analysis

Off-line analysis is equivalent to transmitting/capturing a file in pre-defined channels and decode standards. During off-line analysis the users can analyze the pre-captured *.hdl files. To open the trace for **Offline Analysis**, follow the steps given below:

- Click **File > Off-line** as shown in the figure below Or
- Click **Off line from a File**  from the tool bar




Figure 9: Open a Trace from a File for Off-line Analysis





Figure 10: Offline Analysis

Additionally, the files can be loaded using the command as shown in the figure below:



```

C:\D:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.
D:\>cd program files
D:\Program Files>cd gl com*
D:\Program Files\Gl Communications Inc>cd ss7 ana*
D:\Program Files\Gl Communications Inc\Ss7 Analyzer>ss7prot ss7\Map_ss73.HDL
D:\Program Files\Gl Communications Inc\Ss7 Analyzer>
  
```

Figure 11: Open a Trace File from Command Prompt


3.4 Close Trace

To close the trace file, follow the steps given below:

- Select **File > Close** or
- Click **Close trace**  from the toolbar.

3.5 Save As and Close

To save the trace file using a different name, follow the steps given below:

- Select **File > Save As and Close** menu item Or
- Click **Save Trace to a Different File Name and Close**  from the tool bar




Figure 12: Save Trace As File Name and Close

This feature is usually used to make sure that trace is saved in a different file than temporary trace file and will not be overwritten by accident.

3.6 Save As

To save specific **Frames/Packets** in a new file or to append to an existing file, follow the steps given below:

- Click **File > Save As** Or
- Click **Save As**  from the tool bar.




Figure 13: Save As

- Select **All** to save all the captured frames
- Select **From** to save all the frames whose frame length ranges within the specified values in 'min' to 'max' text boxes as shown in the above figure
- Select **Overwrite** to overwrite the existing *.HDL files in the directory with the new captured frames
- Select **Append** to append the frames/packets to the already existing *.HDL files in the directory.

Trace file remains open after the "**Save As**" operation is completed. Close the trace file and verify if the file has been successfully saved by opening the saved *.HDL file in offline mode.

3.7 Export Details

To export the detail information of frames to an ASCII file, follow the steps given below:

- Click **File > Export Details** Or,
- Click **Export Details**  from the tool bar





Figure 14: Exporting Trace to an ASCII File

3.8 Export Summary

To export the summary information to comma separated values (CSV) format, follow the steps given below:

- Click **File > Export Summary** Or
- Click **Export Summary to a comma delimited file**  from the tool bar

Select the Columns to Export and save the export summary as text file. Select Export Headers to export a header line with column names preceding the summary data rows.




Figure 15: Exporting Summary to an ASCII File

Section 4.0 View Menu Options

The view menu includes -

- Define Views to Display- Summary View; Right-click options in Summary View; Detail View; Hex Dump View; Statistics View;
- Protocol Standard
- User/Network Side Specification
- Time Format
- Latest Frame
- Set filtering criteria
- Activate or Deactivate filter
- Search criteria
- Next, Prev
- Displays trace file name
- Default Summary Columns




Figure 16: View Menu Options

4.1 Define Views to Display

Select **View > Define Views** to select Summary, Detail, Hex-dump, Statistics and/or Call Detail view as shown in the figure below, and click 'OK' to view the details.

**Note:**

Summary View should be selected to view the Detail and /or Hex Dump Views.




Figure 17: Define Views to Display

4.2 Summary View

4.2.1 Setting a Relative Time

Select a particular frame in Summary View and right-click to select **Set Relative Time**.

The relative capture time stamp of all other frames will be calculated relative to the selected frame as shown in the figure below. The selected frame becomes a baseline and the relative time above the selected frame shows that frames are captured before this frame. Also the relative time below this baseline shows that the frames are captured after this frame.

The screenshot shows the SS7 Protocol Analysis software interface. At the top, there is a menu bar with 'File', 'View', 'Capture', 'Statistics', 'Database', 'Call Detail Records', 'Configure', and 'Help'. Below the menu bar is a toolbar with various icons. A 'GoTo' field contains the number '0'. The main window displays a table of frames with the following columns: Dev, TS..., Su..., Frame#, TIME (Relative), Len, Error, BSN, BIB, FSN, FIB, Statu..., and DPC. The table contains 7 rows of data. A context menu is open over the third row (Frame# 3), with the 'Set Relative Time' option selected. Below the table, there is a text area showing 'Card2 TimeSlot=0 Frame=3 at 00:00:00.000000 OK Len=5' and 'HDLC Frame Data + FCS'. This is followed by a detailed breakdown of the MTP2 Layer fields: BSN = .0010001 (17), BIB = 1..... (1), FSN = .0010011 (19), and FIB = 1..... (1). Below this is a 'Hex Dump of the Frame Data' section showing the hex value '91 93 00 5C 26'. At the bottom of the window, the status bar indicates 'Off-line Viewing' and 'E:\Program Files\Gl Communicatio 66872 Frames'.

Dev	TS...	Su...	Frame#	TIME (Relative)	Len	Error	BSN	BIB	FSN	FIB	Statu...	DPC
✓ 1	0		0	-00:00:00.001375	5		19	1	17	1		
✓ 2	0		1	-00:00:00.000750	5		17	1	19	1		
✓ 1	0		2	-00:00:00.000500	5		19	1	17	1		
✓ 2	0		3	00:00:00.000000					19	1		
✓ 1	0		4	00:00:00.000250					17	1		
✓ 2	0		5	00:00:00.000750					19	1		
✓ 1	0		6	00:00:00.001000					17	1		
✓ 2	0		7	00:00:00.001250					19	1		

```

Card2 TimeSlot=0 Frame=3 at 00:00:00.000000 OK Len=5
HDLC Frame Data + FCS
===== MTP2 Layer =====
BSN = .0010001 (17)
BIB = 1..... (1)
FSN = .0010011 (19)
FIB = 1..... (1)


Hex Dump of the Frame Data
+-----+-----+-----+-----+-----+-----+
91 93 00 5C 26
    
```

Off-line Viewing E:\Program Files\Gl Communicatio 66872 Frames

Figure 18: Set Relative Time

4.2.2 Summary Column Selection

Select a particular frame in summary view and right-click to select **Summary Column Selection** or

click on the  button from **Configure > Protocol and GUI Options** to open the **Analyzer GUI and Protocol Configuration** window as shown in the figure below:




Figure 19: Select Columns to Display

This window is used to select the columns that are to be displayed in the Summary View. The default summary view displays the following information in the tabular format:

- **Device Number (one relative)**-It displays the device number on which the data is being captured.
- **Time Slots**- This field displays range of selected timeslots.
- **Sub Channels**- This field displays subchannel number if any selected.
- **Frame Number (zero relative)** - This represents the unique number assigned to each frame in the order in which it was captured.
- **Time** - This field displays the time as configured by the user in **View > Time Format**. For more information, refer to [Time Displays](#).
- **Frame Length (Including 16 bit FCS)** - This field displays the length of each captured frame.
- **Frame Error Status** - This field displays various error messages during capturing /decoding such as Frame error, Decode error, FCS error, and so on.

Additional columns may be displayed corresponding to the protocol standard selected. For details, refer to [Define Summary Columns](#)

Select the desired columns to be displayed from DISPLAYED Summary columns pane to display the columns in the summary view.

- Click **All Columns** to display all the columns in the Summary View.
- Click **Sel Only** to display a particular column in the Summary View.
- Click and drag columns up and down in the “**DISPLAYED**” summary column list to reorder them.
- Click and drag the columns to the right side of the pane to delete them or use the keyboard “Delete” key.
- Click **Undo Delete** or **Restore** to get the columns back to the left pane.
- Click **Display Selected Columns** from the **HIDDEN Summary** columns pane to view the columns, which are hidden.

In addition to column selection, this window allows users to reorder the columns appearance that is displayed in the Summary View, which is explained in the section below.

4.2.3 Column Resizing and Reordering

The users can resize and/or reorder the columns in Summary View. From **Select Summary Columns** window (under **Configure > Protocol and GUI Options**), click and drag the columns to different positions as shown in the figure below. The figure shows the **Time (Relative)** and **Len** columns are reordered and **TSlot** and **Frame #** columns are resized.




Figure 20: Column Resizing and Reordering

In addition to reordering, the Summary columns can be resized. Click and drag the Summary column headers to resize them.

4.2.4 Repositioning Summary View

Enter a new current frame number to position at the top of the summary view and click **GoTo** button as shown in the figure below:




Figure 21: Repositioning the Summary View

This operation may be executed even during the real-time capturing. If filter is active the frame number refers to displayed (filtered out) frames.

4.2.5 Summary Colors

Select a frame in Summary View and right-click to select **Summary Colors** as shown in the figure below. Summary View is shown in different colors based on the selected columns. For example, select **Len** (Frame Length) option and click **Ok**.




Figure 22: Set Summary Colors

Observe that different colors are set based on the values in the **Len** column, in other words, the frames having the same length values will have a unique color set for it as shown in the figure above.

4.2.6 Define Views

For detail information on this refer to section [Define Views to Display](#).

4.3 Detail View - Selecting Individual Frame

Click to highlight a frame in Summary View to display the frame-specific details in the **Detail View**. Each line in the detail view displays field offset and upon selection of this offset the corresponding hex dump view bytes are highlighted,

The screenshot displays the SS7 Protocol Analysis 557 ITU software. The main window shows a table of frames with the following columns: Dev, TSlot, SubCh, Frame#, TIME (...), Len, Error, BSN, BIB, FSN, FIB, Status Field, and SLC. The first frame (Frame# 0) is selected and highlighted in red. Below the table, the detailed view for Frame# 0 is shown, including the following information:

```

Card1 TimeSlot=0 Frame=0 at 00:00:00.000000 OK Len=70
HDLC Frame Data + FCS
===== MTP2 Layer =====
0000 BSN = .0100101 (37)
0000 BIB = 1..... (1)
0001 FSN = .0100100 (36)
0001 FIB = 1..... (1)
0002 LI = .111111 MSU Format
===== MTP3 Layer =====
0003 Service Indicator = ....0011 SCCP
  
```

Below the protocol layer information, a hex dump of the frame data is displayed:

```

Hex Dump of the Frame Data
+-----+-----+-----+-----+-----+-----+
A5 A4 3F 83 1E B1 01 0A B1 01 0B 09 00 03 05 07  #P? | ± ±
02 C1 06 02 C1 05 2D E2 2B C7 04 1B 95 34 01 E8  Á Á -á+Ç |4 è
23 E9 21 CF 01 00 D1 02 09 0D F2 18 88 05 59 24  #é|Ï Ñ ò |Y$
00 00 00 89 04 01 0B 00 00 91 01 03 96 01 06 95  | | | |
  
```

The status bar at the bottom indicates "Off-line Viewing" and "C:\Program Files (x86)\GL Communica 43 Frames".

Figure 23: Detail View of Individual Frame

The Detail View displays frame information in the following sequence:

- Frame Summary Information
- MTP (Message Transfer Part Level 2) Layer
- MTP 3 Layer (Message Transfer Part Level 3) Layer
- Layer 3 information
 - SCCP Layer
 - ISUP (ISDN User Part) Layer
 - MAP Layer
 - INAP Layer
 - INAP CS2 ITU Layer
 - INAP CS2 ETSI Layer
 - IUP (Interconnect User Part) Layer
 - Network Mgmt Messages Layer
 - Reg Test Messages Layer




Figure 24: SS7 Over IP

The following image displays MTP2 Layer messages decoded in High Speed Link:




Figure 25: MTP2 Layer Coded in HSL

4.3.1 Layer Copy/Show/Hide Options

- 1) Right-click in the Detail View and select '**Layer Show/Hide**' option to display or hide the required protocol layers.




Figure 26: Selecting Show Layer Option

- 2) One can also select the **Copy** option to copy the entire layer decode information to the clipboard. Refer to the figure below:




Figure 27: Copying Detail View Information

4.4 Hex Dump View

Hex Dump view displays raw frame data as a hexadecimal and an ASCII octet dump.

4.5 Statistics View

Various statistics can be calculated based on the protocol fields. For more information refer to the [Statistics](#) section.

4.6 Protocol Standard

Select **View > Protocol** to select the decoding standard to be used to parse and display information. The decoding standard does not affect information saved to a disk file and therefore can be changed at any time.




Figure 28: Select Protocol Standard

4.7 User/Network Side Specification

Select **As Captured** option button to retain the selected user/network options at the time of capturing.
Select **Inverse Captured** option to inverse the selected user/network options effective at the time of capturing.

Select **User Defined** option button to specify the network side cards. This option can be specified when multiple cards are used. Enter the card number, which should be on the network side.

The user/network side specification is set initially using the **Capture Options > Stream/ Interface** dialog as explained in the section [User / Network Side Specification](#).




Figure 29: User/Network Side Specifications

4.8 Time Displays

Four time formats are supported for both **real-time** and **offline** analysis. These time formats can be changed during both off-line and real-time operations by selecting the required time format either from **View > Time Format** menu item or by clicking on the time column header in the Summary View shown in the figure below.

- Relative time
- System time
- Date and time
- Difference time




Figure 30: Time Displays

4.8.1 Relative Time

In the **Relative time** format, the time of capture of each frame is displayed relative to the time of a selected frame. In this format, time value of the selected frame when the option is activated is always 0:00:00:000000.

If, for instance, second frame has the time value as 0:00:20:000000, it means that second frame was captured after 20 seconds since the first frame was captured. Thus the time value corresponding to each frame is obtained by the difference between the time of capture of that frame and time of capture of 0th frame. Preceding frames have negative relative time and following frames have positive relative time.

4.8.2 System Time

This option displays the system (local computer) time when frames were captured. For offline analysis, the system time option shows the time when the trace was captured earlier.

For instance, during real-time capture, if the capture time displayed for the first frame is 14:53:24:015411, it means that the first frame was captured at 2.53 P.M., 24 seconds, 015411 microseconds local system time.

4.8.3 Date and Time

Date and Time format shows local date and system (PC) time during the real-time capturing of the frames. For off-line analysis, the system time option shows the date and time when the trace was captured earlier. The display is in the form of year, month, day, hours, minutes, seconds and microseconds.

4.8.4 Difference Time

The Time Difference format displays the time difference between consecutive frame capture times. For each frame it is this frame time minus the preceding frame time.

4.9 Latest

**Note:**

This feature is applicable to real-time analyzer only.

The **View > Latest** option enables/disables automatic screen refresh and repositioning of the Summary and Detail View to the latest captured frame. This option does not have any effect in the off-line analysis mode and is used only for real-time analysis to refresh screen approximately every two seconds. When the menu option is checked the automatic repositioning to the latest captured frame is enabled.




Figure 31: Auto Screen Refresh During Real-time Analysis

4.10 View Filtering Criteria

The **View Filter** is used real-time and offline to display and subsequently save, export and print a subset of frames satisfying a certain filtering criterion. The active filter is used as WYSIWYG (What You See Is What You Get). When filtering is active, the subsequent save as, export and or print will apply only to the filtered frames, otherwise, all the frames will be affected by the operation.

All captured frames are preserved and will be displayed when filter is deactivated. The filtering criterion is effective either until the criterion is changed, de-activated or the analyzer is closed. After the filtering criterion has been specified, the frame filtering can be activated or de-activated at any time.

4.10.1 Setting Filtering Criteria



The filtering criteria are set for protocol fields and various parameters supported for the respective protocol standard. It resembles a tree-like structure, which displays various layer components based on the protocol standard selection chosen in **View Menu > Protocol Standard Selection menu**.

To view filter (or search) selections, select **View > Protocol Standard Selection > View Filter**.

The parameters satisfying the conditions may be included or excluded from the result using the **Include** or **Exclude** options. All the selected criteria logically use **OR** or **AND** operations. A frame is filtered if at least one criterion matches (OR logic), or each criteria matches (AND logic).

Note:

For more information on the parameters provided in the filtering criteria, refer to the section **Appendix A - Filtering and Search Criteria**.

- Select **View > Filtering Criteria** menu item or
- Click **Filtering Criteria**  from the toolbar. The filter selection dialog is displayed as shown in the figure below
- Click on the  **View Filter** button from **Configure > Protocol and GUI Options**





Figure 32: Setting Filtering Criteria

Just setting the filtering criteria is not sufficient to start filtering. After the filtering criteria have been set, activate filter as explained below.

4.10.2 Activate Filter

Activate filter activates the filtering criterion and displays only filtered frames.

- Select **View > Activate Filter** menu item as shown in the figure below or
- Click **Activate Filter**  from the toolbar





Figure 33: Activating Filter

If no filtering criterion is selected, both **View > Activate Filter** menu item and the corresponding button are disabled. Therefore, setting filtering criteria must precede the filter activation.

The active filter affects subsequent save, export and print operations. It works as WYSIWYG (what you see is what you get).

4.10.3 Deactivating Filter

Deactivating filter removes filtering and displays all the frames in the trace.

- Select **View > No Filtering** menu item as shown in the figure below or
- Click **Deactivate Filter**  from the toolbar




Figure 34: Deactivating Filter

4.10.4 Example - View Filter

To filter out frames with errors and display only the erred frames, follow the steps below:

- 1) Expand **Data Link Layer**. Select **Error Frames Only** option as shown in the figure below to filter all error frames.
- 2) Enter the character 'y' in the entry field and click **Activate** to apply the settings.
- 3) Select **Include** radio button and close the **View Filter** window to apply the settings.
- 4) If more than one filter condition is required, select the AND / OR option accordingly.






Figure 35: Example - Filter Option to filter Error Frames Only

4.11 Searching for Specific Frames

First, the search criterion has to be set and then 'Next' or 'Prev' function is invoked to search from the current record towards end of trace (next) or beginning of the trace (prev). If filtering is active the search operation is conducted among the already filtered frames.

- Select **View > Search Criteria** menu item or
- Click **Find**  from the toolbar to open search criteria window as shown in the figure below
- Click on the  View Search button from **Configure > Protocol and GUI Options**




Figure 36: Setting Search Criteria

4.12 Forward Search & Backward Search





Figure 37: Searching Forward or Backward Options


4.12.1 Searching Towards the End of the Trace (Forward Search)

This operation will search from the current Frame in the summary view towards the end of the trace. To invoke this operation, follow the steps given below:

- Select **View > Next** menu item as shown in the figure below or
- Click  from the toolbar

4.12.2 Searching Towards the Beginning of the Trace (Backward Search)

This operation will search from the current frame in the summary view towards the beginning of the trace. To invoke this operation, follow the steps given below:

- Select **View > Prev** menu item as shown in the figure below or
- Click  from the toolbar

4.12.3 Example - Search for particular frames

Use the search option to search for particular frames of interest, among the displayed frames. For example, to search for all frames with frame length between 40 to 100, captured on device # 2, follow the steps below:

- 1) Expand **Data Link Layer**. Select **Frame Length** option as shown in the figure below.
- 2) Enter the range '40-100' in the entry field.
- 3) Further to search frames captured on a particular device, select **Card.Timeslot.Subchannel**.
- 4) Enter the value as '2' in the entry field. The format in which this information can be entered is as follows: Card#...Card#.Timeslot#...Card#.Timeslot#.Subchannel#
- 5) Click **Activate** to apply the settings.
- 6) Select **Include** radio button and select the AND option to search for frames that meet both criteria.
- 7) Close the **View Search** window to apply the settings.




Figure 38: Example - Search option to search for frames of specific length

4.13 Display Trace File Name

Select **View > Display trace file Name** menu item to view the filename under which the analyzer capture frames during real time or offline-trace as shown in the figure below. This option is useful when the file name is very long and is truncated in the status pane.




Figure 39: Trace File Name

4.14 Default Summary Columns

To return to the **Default Summary Columns** from resized/reordered columns, click the **View > Default Summary Columns** option as shown in the figure below:




Figure 40: Default Summary Columns

(Intentional Blank Page)

Section 5.0 Capture Menu Features

Note: Capture Menu features is applicable to real time analyzer only.

5.1 Periodic trace saving options

Periodic trace saving is used to preserve all real-time captured data, limited only by the available amount of hard disk space. Frames can be saved to separate trace files based on the frame size or time criteria.

Select, **Capture > Periodic File Saving Specifications**, to open the screen as shown in the figure below.





Figure 41: Periodic File Saving Specifications

Save Directory:

Click  browse button to select the path of the directory where the files will be saved.

Save File Names:**Sequential File Names**

This file naming convention saves the trace files with user-defined prefixes along with the numbers indicating the sequence of the file. Select **Sequential File Names** radio button and enter a name in the **file name prefix** entry field. Use the slider control to indicate the total number of files to be saved. You can drag the slider handle to any position using the mouse or simply click to the left or right of the slider handle to move it. You can control the slider by number of digits.

Example: Enter the file name prefix as 'ff' and set the slider control to third position of the ruler in the number of digits slider box. Now the files will be saved from ff000 up to ff999 in the user-defined directory.

Date/Time Formatted Names:

This file naming convention saves the trace file with date-time prefixes. Select **Date/Time Formatted Names** radio button to obtain the file name saved with the year, month, date, and hour.

Example:

Enter the file name prefix as %Y%M%D_%H%I in the **Date/Time Formatted Names** text box. Verify that the trace files are saved in '20050531_0953.HDL' format in the user-defined directory. The formatting specification refers to the year, month, day, hour and minute (date and time stamp).

Create a New File After the Specified Limit has been Reached:

Select either **File Size Limit**, **Frame Count Limit**, or **Time Limit** option and specify the limit in the Limit Value entry field.

Restrict or Recycle After N Files Options:

Select **Keep N Latest files**, **Stop After N Files**, or, **Unrestricted** option to get the desired number of trace files.

Keep N Latest files – Restricts the file saving only for last 'N' number of files, where 'N' is the value set in the text box. When **N** is reached the older files will be overwritten by the most recent files keeping the total number of files equal to N.

Stop After N Files - Restricts the file saving only for first 'N' number of files, where 'N' is the value set in the text box. After the limit has been reached, the periodic saving stops.

Unrestricted - This option does not restrict the number of files being saved. This option limits the periodic saving to the available disk space only.

For Example:

Enter the value as 10(N=10) in the entry field and select **Keep N Latest files** radio button. Only ten files will be kept. They will contain the latest captured data.

Enter the value as 10(N=10) in the entry field and select **Stop After N Files** radio button. Initial 10 files are obtained and the process is stopped.

Note: Select **Enable Periodic Saving** and **Start real-time tracing** options (provided under **Configure > Startup Options**) before setting the Periodic File Saving Specifications.

5.2 Setting Capturing Options




Figure 42: Capturing Options

From the main menu select **Capture > Capture File Options** specify a temporary file name for capturing, the maximum size of this file in bytes and the capturing limit in frames or time period. Capturing options supports handling frames on 64 bit processor.

The capture settings are saved in the Windows registry when the user exits the application. They need not be entered each time application is started.

Specific settings can also be saved using Save menu option and subsequently loaded when needed.

The file name can be either typed in the entry field or selected using the file dialog by clicking "..." button. The limit in bytes should be specified as a positive number, for example, 50000000 indicate that the maximum trace file size is 50Mb. If the limit is specified using the time format, for example, 12:22:20, then capturing stops after 12 hours, 22 minutes and 20 seconds.

Capturing stops when either the maximum trace file size in bytes is reached or the capturing limit is exceeded when circular capture buffer is not used.

5.2.1 In Memory for High Traffic Capture Rate

In case of high traffic rate (>50 Mbps), select the **In Memory** check box to get better performance. This will store all the frames in primary memory instead of writing to trace file on the disk till the trace file is closed. Frames will be written to trace file only when analyzer is closed. This option is used when disk is not fast enough to keep with capturing speed but if in-memory file is large, say 500 MB it will take a while to close the trace file.

5.2.2 Circular Capture Buffer


For infinite capturing, select the "**Circular Capture Buffer**" check box. When end of the capturing buffer is reached, the capturing does not stop. Instead, the oldest trace records are purged from the buffer and the new ones are placed at the end of the circular buffer.

Note: The maximum file size in bytes can be set from **64k** (2^{16}) to **2G** (2^{31-1}) Only. When capturing is completed the unused reserved bytes are released. Closed trace file will shrink to the minimum size sufficient to hold the captured information.

Various options are available for saving trace file, refer to Periodic Trace Saving Options for details.

5.3 Stream /Interface (Port) Selection

The **Stream /Interface Selection** dialog allows a user to specify ports for monitoring, and user/network side capture. To open the **Stream /Interface Selection**, follow the steps below:

- Select the **Capture > Stream/Interface Selection** as shown in the figure or
- Click **Stream/Interface**  from the toolbar




Figure 43: Stream/Interface Selection

5.3.1 Port and Timeslots Selection

The time-slot selection dialog allows user to specify devices and corresponding time slots on which the data is being captured.

For T1, all (0-23) or required timeslots may be selected.

While for E1 systems, excluding timeslots 0 and 16 (for CAS signaling only), all or the required timeslots may be selected.

Selection of timeslots may be contiguous or non-contiguous (N*64 kbps Hyper-Channel, Single channel and Sub channels).

Optionally, frames may also be captured based on their FCS (16 bits, 32 bits, none).

Note: For N*56 kbps Hyper-Channel selection, the selection of timeslots should be contiguous.

5.3.2 User/ Network Side Specification

This option is used in protocol analysis for selection of uplink or downlink monitoring.

Along with the port selections, users can specify if the card is monitoring the traffic from user-side or from network-side. If user is monitoring traffic originated from user-side (uplink), then cards should be unchecked and for capturing traffic originated from network-side (downlink), the cards should be checked as shown in the figure below.. The user/network side specification may also be set using the **View>User/Network Side Specification** dialog as explained in [User/Network Side Specification](#).




Figure 44: User/ Network Side Specification

Note: The first check box is meant for card1, the second for card2, and so on.

5.3.3 Bit Inversion

Bit inversion changes each bit in received octets from 0 to 1 and 1 to 0. (See the figure below)

Check the box as shown in the figure below to enable bit inversion.




Figure 45: Specifying Bit Inversion Option

5.3.4 Octet Bit Reversion

Octet bit reversion changes order of bits in each octet in such a way that the most significant bit becomes the least significant bit. For example, 0101001 is changed to 1001010. (See the figure below)




Figure 46: Specifying Octet Bit Reversion Option

Note: Both inversion and reversion must be used with care. In most cases bit inversion and reversion are not used in real-time systems.

5.3.5 HDLC FCS




Figure 47: Specifying FCS Value

This allows users to decode frames with FCS 16 bits, FCS 32bits, or no FCS options.

All as Port1: The settings of port 1 is applied to other ports

All as Port 1, 2: In case of multiple ports the settings of port1 and 2 are replicated to all odd ports and even ports respectively. For ex: settings of port1 are replicated to port 3 and so on.

5.3.6 Data Transmission Rate




Figure 48: Specifying Channel Selections

Selection of the data transmission rate in various modes like single channel, sub channels, or hyper-channels is possible.

Single Channel

If all eight bits in a byte are used for data transmission, then this is referred to as **64 kbps** format. If only seven bits out of eight are used for data transmission, then this is referred to as **56 kbps** format.

Hyper Channel

Multiple channels may be defined per card.

Nx64 Kbps: This indicates selection of multiple timeslots (contiguous or non-contiguous) each of 64 Kbps

Nx56 Kbps (Bits 1-7): This indicates selection of multiple timeslots (contiguous) of each 56 Kbps with bits selected (1-7)


Nx56 Kbps (Bits 2-8): This indicates selection of multiple timeslots (contiguous) of each 56 Kbps with bits selected (2-8)

Sub channel

In addition, the data may be transmitted on any of the user-defined bits (contiguous only), in which case, the user must select one of the options and its corresponding DS0 bits under **Subchannels 8-56 kbps** pane. The actual sub channels comprising a lower bandwidth pipe are selected using the subchannel selection list box.

Depending on data transmission rate, the number of subchannels can be selected according to the table below. Each pipe 8 - 56 kbps can be comprised only from the contiguous subchannels. For example for 32 kbps pipe the following sub channel selections are valid 1-4,2-5, 3-6, 4-7. On the other hand, selecting subchannels 1, 2, 4 and 5 for 32 kbps is invalid: the total bandwidth is 32 kbps for these four selected subchannels, however they are not contiguous.

Subchannel Rate	Subchannels per Time Slot	Example	Example Explanation
8	1,2,3,4,5,6,7,8		Three Independent pipes are specified: 1-2, 4 and 6. Each is 8 kbps
16	1,2,3,4		Two pipes 16 kbps each are specified. These two pipes are 1-2 & 3-4
24	1,2		Two pipes 24 kbps each are specified. First pipe 1-3 subchannels, second 6-8 subchannels
32	1,2		Two 32kbps pipes take entire DS0. First one 1-4 subchannels, second 5-8 subchannels

40	1		One pipe 40 kbps takes subchannels 1-5.
48	1	Similar to 40 kbps but 6 consecutive subchannels must be selected	
56	1	Similar to 40 kbps but 7 consecutive subchannels must be selected	

5.4 Setting Capture Filter using Real-time Analyzer

Select **Capture > Capture Filter** option to directly exclude **LSSU** (Link Status Signal Unit), **FISU** (Fill-in Signal Unit) frames or any other user-defined frames. **LSSU** frames (of length 5) communicate information about the signaling link between the nodes on either end of the link. **FISU** frames (of length 7) support the monitoring of link traffic because they undergo error checking

For example, enter the number of the frames, say 5 and 7, and **click OK** as shown in the figure below. Frames of length 5 and 7 will be excluded during real-time capture.




Figure 49: Capture Filter

Note:

Capture Filter is not applicable for CAS Analyzer

5.5 Capture Physical Layer Alarms

Select **Capture** → **Capture Physical Layer Alarms** option to capture the status of the physical layer alarms.




Figure 50: Capture Filter – Select Protocol Value

5.6 GUI and Protocol Options

Switches to GUI and protocol list: selecting columns, protocol standard, filtering criteria, search criteria, etc. For more information refer to [Protocol Analyzer Configuration](#).

(Intentional Blank Page)

Section 6.0 Statistics

Protocol statistics is one of the main features of protocol analyzers. **Statistics are calculated based on the protocol fields.** The pane displaying statistics in protocol analyzer is as shown in the figure below:




Figure 51: Protocol Analysis with Statistics View

6.1 Steps to Display Statistics

Statistics can be calculated and displayed in off-line and real-time modes.

In both cases statistics must be defined first using **Define/Edit** dialog as shown in the figure below and subsequently statistics view must be opened using the **Statistics > Open Statistics View** or using **View > Define Views to Display**.

For real-time capturing, statistics view must be open before tracing is started.




Figure 52: Statistics Definition Dialogue

The statistics definition dialog has the following elements:

- **Field Names** displayed as tree view in the upper left corner. This tree view is used to select a parameter for statistics calculation for the appropriate layer.
- **Use Type (UT)** selection list box in the upper right corner allows users to select either **Total, Key or Field type** as statistics calculation type for each field name.
- **Statistics Type (ST)** list box allows users to select additional parameters (Frame count, Current Frames, Max, Min etc) for each of the field name selected. Selecting a parameter under this frame is a *must*, if the user has selected any **Field Name** as **Use Type**.
- **Range List, Value Set or Wild Card** can be specified in the entry field below the statistics type list box to further narrow down the selection for the required statistics calculation.
- **Add/Mod (Add/ Modify)** button is used to apply all the values selected for each field for calculation. On the contrary, the **Remove** button is used to remove the selections made for each field name.
- Once the **Add/Mod button** is clicked, the **Selected Statistics Information** pane at the bottom of the dialog lists the conditions set for each field and provides buttons to remove the selected or all settings. All fields defined as Total UT, Key UT or Field UT must appear in this pane to participate in statistics calculation as shown in the figure above.

6.1.1 Selecting Field Names (Step 1)

In the protocol tree view, navigate to the protocol layer to which the field item belongs and click to select this item. The supported layers for the protocol analyzer and the field parameters for respective layer will be displayed as shown in the figure below:




Figure 53: Selecting Field Names

Classifying Fields under Field Names

All field names in the protocol displayed in the tree view belong to one of three types:

- Numeric
- String
- Enumerated (set)

Field names can be distinguished based on the icons representing them as shown in the figure below.




Figure 54: Field Types

6.1.2 Defining Use Type (UT) and Statistics Type (Step 2)

Use Type (UT)

The UT can be total, key or field types. Selecting proper type defines the table displayed in the Statistics View. At least one total or key UT must be defined. Total and Key UT directs creation of statistics view columns for the selected fields and also rows with unique aggregate value of Total and Key columns.

Total UT has dual role. Firstly it's used as a **Key UT**, defining rows with unique set of column values in the Statistics View. Secondly, it directs the statistics engine to display an additional row for totals (sum). The latter is similar to the sum function in the spreadsheets.

Unique set of column values means that different rows have a unique combination of values in the Key/Total columns.

Field UT defines only separate columns where the calculated Statistic Type is placed for the combination of key values.

The UT can be set as **Total, Key or Field**. A minimum of one UT must be defined for each field selected under **Field Names**.

Statistics Type (ST)

The following statistic types are available:

- Frame Count
- Frame Percent
- Byte Count
- Byte Percent
- Current Frames/Sec
- Current Bytes/Sec
- MAX Frames/Sec
- MAX Bytes/Secs
- MIN Frames/Sec
- MIN Bytes/Sec
- AVG Frames/Sec
- AVG Bytes/Sec
- MIN
- MAX
- SUM
- AVG

MIN, MAX, SUM and AVG should be specified only for numeric fields. As explained in the section Classifying Fields under Field Names, all the fields belong to one of the following categories: numeric, string and enumerated (sets). When the same ST is specified for multiple fields, a new column is created in the statistics view for each field name.

Additional columns consume resources and slow down statistics calculation process. Only MIN, MAX, SUM and AVG columns will be different for different fields, other columns like Frame Count, Frame Percent, Byte Count and more will display the same information and will not be useful.

6.1.3 Update Selected Statistics Information List (Step 3)




Figure 55: Selected Statistics Information List

After selecting the required Use Type and statistics Type, click **Add/Mod** button to add the selected statistics in the information list.

Click **Apply** shown on the figure above to activate the newly defined statistics information. If the Statistics Definition dialogue is closed without clicking on the **Apply** button will discard all the **newly** defined statistics.

6.1.4 Example 1 - Statistics with a Key UT

Key UT: This option creates a unique column in the Statistic View, and a row for each unique value combination associated with all key and total columns. For example:

- 1) Open the sample trace file in offline analysis mode.
- 2) To define statistics, click Statistics > Define/Edit.
- 3) Select the field 'Device #' under physical layer, and select Key UT as the use-type., and Frame Count as statistics type
- 4) Click Add/Mod button and then click Apply. The selected statistics pane appears as shown in the figure below.




Figure 56: Define Statistics with a Key UT

- Click **Statistics > Open Statistics View** to open the statistics frame which appears as shown in the figure below:




Figure 57: Statistics with a Key UT

In the above example, the data is captured using device # 1 and 2, and therefore the key values of 1 and 2 are displayed under the **Device#** column.

6.1.5 Example 2 - Statistics with a Total and a Key

Total UT: This option not only makes the column a key column but also creates an additional total row for each unique value of the column.

Total UT and Key UT values combined together uniquely define a row in the Statistics View.

Key UT: Key UT defines a unique column value that can be used for calculating a Statistic Type like frame count, sum, avg, min, max, etc. This calculated statistics will be displayed only if all the key UT values are unique and are numeric else the statistics View displays just the word 'Total' in the row dedicated for the same purpose. For example -

- Open the sample trace file in offline analysis mode.
- To define statistics, click **Statistics > Define/Edit**.
- Select the field **'Device #'** under physical layer, and choose **Total UT** as the use-type and then select **Frame Count** as statistics type.
- Click **Add/Mod** button and then click **Apply**.
- Select the field 'C/R' under LAPD layer, and then select **Key UT** as the use-type.

- Click **Add/Mod** button and then click **Apply**. The selected statistics pane appears as shown in the figure below.




Figure 58: Select Statistics with a Total and a Key

- 7) Click **Statistics > Open Statistics View** to open the Statistics View as shown in the figure below:




Figure 59: Statistics with a Total and a Key

In the above example, unique rows are defined based on field (C/R values) selected as the Key UT, and columns (frame count for each device) are defined based on the statistics type selected for this Total UT. Since the device is selected as Total UT, additional row displaying the total frame count per device are displayed.

6.1.6 Example 3 - Statistics Total and Field UT

Field UT: This option defines additional columns for the parameters selected under **Statistics Type** frame. **Field UT** creates just an additional column for the selected field. However, differently from Key UT and Total UT, the Field UT does not create additional rows for each unique value associated with the field. For example,

- 1) Open the sample trace file offline.
- 2) To define statistics, click **Statistics > Define/Edit**.
- 3) Select the field **'Device #'** under physical layer, and choose **Total UT** as use-type.
- 4) Select **Timestamp** under **'Physical Layer'**, and choose **Field UT** as use-type. To get the frame count for each unique timestamp, select **Frame Count** as the **Statistics Type**.

Note:

Notice that setting the **Timestamp** as a Field UT does not create unique rows for each unique timestamp value as in the previous example where the UT was set as the Key UT.

6.1.7 Ranges, Wildcards And Enumerated Value Sets

Depending on the field type additional criteria may be specified to include only frames with the matching:

- Ranges for numeric fields
- Wildcards for string fields
- Sets of values for enumerated fields

Ranges

Depending on the field type a range list can be specified for numeric fields as space separated numbers or segments of numbers. For example, the range list 1 12-15 4-6 will include fields with the following integer values: 1, 4, 5, 6, 12, 13, 14, and 15. Frames with all other values will be excluded from statistics see the below figure

Ranges are valid only for numeric fields.




Figure 60 : Range List for Numeric Fields

Wildcards

Valid string field values can be specified using wildcard characters '*' (asterisk) and '?'. (question mark)

'*' means any zero or more characters

'?' means any single character

'301*', for example, means any string starting with '301'

'301*5*' means any string starting with '301' and containing '5'

'*3?4?5*' means string containing '3' followed by any single character followed by '4' followed by any single character followed by '5'.

Wildcards are valid only for string fields.




Figure 61: Wildcards for String fields

Value Sets

Enumerated fields can have a fixed set of values assigned a string name. Some of these string names can be selected to narrow down the statistics. See the figure below.




Figure 62: Specifying Value Sets

6.1.8 Modifying and/or removing configured statistics




Figure 63: Modify/Remove some or all statistics

In the process of the statistics definition one can go to the **Selected Statistics Information** list control and select a line by clicking on it. This will cause automatic repositioning of the tree view and statistics information for the selected field to be displayed in the UT, ST and **Range/Wildcard/Value Set dialog controls**. User can then modify the information and click **Add/Mod** button to make the changes effective as shown in the figure of the **Selected Statistics Information list**.

Click **Remove Sel** button to remove selected lines from the criteria.

Click **Remove All** to disable statistics.

6.2 Opening and Closing Statistics View

Statistics view can be opened and closed any time during offline analysis. Opening a trace view can be a lengthy process for large traces when statistics is enabled.

Statistics view for on-line tracing must be opened before real time analysis is started.

To open Statistics View select **Statistics > Open Statistics** view menu item as shown in the figure below.




Figure 64: Opening and Closing Statistics View

To close the Statistics view, select **Statistics > Close** statistics view menu item.

6.3 Loading Statistics

Select **Statistics > Load Statistics** (to load the saved statistics criteria as shown in figure below). One can load the statistics from a previously saved Statistics Definition File (*.ini).




Figure 65: Loading Statistics

6.4 Load and Edit Statistics

Select **Statistics > Load and edit statistics** (to load the saved statistics and to modify the statistics information).

6.5 Save Statistics

Select **Statistics > Save Statistics** to save the statistics. **Save Statistics** saves the file with configuration details. Enter the desired file name and click **Save**, the statistics file is saved with extension name ``.ini'` (Statistics Definition Files).

Enter the desired file name and click **'Save'**, the statistics file is saved with extension name ``.Ini'` (Statistics Definition Files).




Figure 66: Save Statistics as Filename

6.6 Export Statistics

Select **Statistics > Export Statistics** to export the statistics view into a file with extension **'sef'** (Statistics Export Files) for subsequent import into a database or spreadsheet.




Figure 67: Export Statistics as Filename

Section 7.0 Call Detail Records

The objective of call detail record is to isolate call specific information for each individual call from the captured data and display the information in an organized fashion. The call-detail records are displayed as shown in the figure below.




Figure 68: Call Detail Records View

7.1 Build Call Detail Record

Select **Call Detail Record > Build Call Detail Record** menu item as shown in the figure below. Build Call Detail Record is checked for the activation of call trace application. This should be done before starting the real-time capture or before opening an **hdl** file in offline mode.




Figure 69: Build Call Detail Record

7.2 Select Call Detail Columns to Display

Select **Call Detail Record > Select Call Detail Columns to Display** menu item as shown in the figure below. This contains a list of possible Columns. Here we can select the interested columns using ctrl key and click **OK**.

 Note:

The Columns can also be selected after opening the Call Data Record view by right-clicking on pane and choosing 'Select Columns' option.




Figure 70: Select Call Trace Columns to Display

Call ID details, the calling status whether the call is active or completed, calling number, called number, call start date and time, call duration, release cause, device number, and so on, are shown in the call trace view.

7.3 Active Calls Only

Select **Call Detail Record > Active Calls Only** menu item to view all the active calls.

7.4 Open Call Detail Record

Select **Call Detail Record > Open Call Detail Record** menu item. Call Detail Record View can be opened and closed in off-line trace viewing any time.

To open Call Detail Record View

- Select **Call Detail Record > Open Call Detail Records** menu item or
- Click **View > Define Views** menu item.




Figure 71: Open Call Detailed Record



Note:

- Build Call Detail Record menu item should be checked before opening Call Detail Records view.
- If the Call Trace view is selected from View>Define Views to Display menu item without checking Build Call Detail Record, a warning message is displayed as shown in the figure below.
- Call Detail Record View for on-line tracing must be opened before on-line tracing is started.




Figure 72: Warning Message

7.5 Call Detail View

The following call trace details are available in the Call Detail View.

- **Call ID** – a unique call identifier assigned to each call.
- **Call Status** - displays the call status as "C IaArR" or "A IaA" where,
 - the first letter 'A' denotes an Active call
 - the first letter 'C' denotes Completed call
 - Subsequent letters are denoted as follows -
 - 'I' denotes Initial Address Message
 - 'a' denotes Address Complete Message
 - 'A' denotes Answer Message
 - 'r' denotes Release
 - 'R' denotes Release Complete Message

For more information refer to the section [Appendix A: Glossary](#).




Figure 73: Call ID Status for SS7

- **Disp** –various call status information specific to Fairpoint.
- **Calling Number** - identifies the calling number.
- **Called Number** – identifies the called number.
- **Call Start Date and Time** - the date (Y/M/D) and the time at which the call was made.
- **Call Duration** - duration of the completed call.
- **Release Complete Cause** - call termination cause.
- **Device number**- port number on which the call was captured.
- **Timeslot (TS)** - channel number on which the call was captured.
- **OPC** –originating point code value.
- **DPC** –destination point code value.
- **CIC (Circuit Identity Code)** - identifies the user channel and it is unique for a call.
- **Link set** - link group carrying signaling information.
- **Carrier CIC** - shows the information sent in the forward direction to the transit network indicating the transit network selected by the originating subscriber.
- **TNS CIC** - transit network for routing of a call.
- **International** - National / International call indicator.
- **Charge No** - number for which the call is charged.

- **OLII - (Originating Line Information)** - toll class of service for the call.
- **JIP** - geographic origination of the call.
- **GAPPDN** - indicates a (Generic Address) pertaining to supplementary services.
- **Billing Duration Secs** - duration for which user is charged. It is AN <->RLZ duration.
- **Out Going Trunk#** - trunk group selected at outgoing gateway.
- **Original Redirecting Reason** —forwarding reason for the original redirection.
- **Redirection Counter** - number of times forwarding of a particular call.
- **Redirecting Reason** - forwarding reason for the last redirection.
- **CDPN Nature** - nature of called party number.
- **OCDN Address** - Original called number.
- **OCDN Nature** - nature of original called party number.
- **CgPN Nature** - nature of calling party number.
- **FCI Bit_M** - more bit indicator.


**Note:**

The following Call Trace Columns is displayed only for CNAM when the user edits SS7_CALLTRACE_TYPE as 2 in the ini file: Call ID, Call Status, Call Start Date & Time, Call Duration, DevNo, TS, OPC, DPC, Call Type, Originating Transaction ID, Response Transaction ID, Calling Directory Number, Generic Names, Release Cause


7.5.1 Active and Completed Calls

Call ID refers to the identification of each call. There are icons visible to the left of these Call ID numbers

Active Calls:

Active calls () are marked in green and the call status is specified as **Active**. An arrow is seen above the letter **A**, which indicates the direction of the call.

Completed Calls:

Completed calls () are marked in grey and the call status is specified as **completed**. An arrow is seen above the symbol (-), which indicates the direction of the call.

7.5.2 Call Duration

Call duration is calculated for completed calls. It is the total time for the call from start till the end of call. The value is represented in *hh.mm.ss.nnnnnn* format.




Figure 74: Active, Completes Calls, and Call Duration

7.5.3 Find CDR

This feature allows you to search for a particular call from the captured traces. Right-click on the Call Detail View and select **Find CDR** option to open the screen as shown below:




Figure 75: Find CDR

Select the parameters from the **Column Name** and enter the criteria in the **Value Wildcard** text box. The parameters satisfying the conditions may be included or excluded from the result using the **Include** or **Exclude** options. All the selected criteria logically use **OR** or **AND** operations. A frame is filtered if at least one criterion matches (OR logic), or each criteria matches (AND logic).

Wildcards

All values in Call Detail View are considered as string. To search for a specific call, valid string field values can be specified using wildcard characters '*' (asterisk) and '?' (question mark)

'*' means any zero or more characters

'?' means any single character

'301*', for example, means any string starting with '301'

'301*5*' means any string starting with '301' and containing '5'

'*3?4?5*' means string containing '3' followed by any single character followed by '4' followed by any single character followed by '5'.

Wildcards are valid only for string fields.

For example, to search for calls with call duration more than 40 seconds, enter the value for Call Duration parameter in the wildcard textbox as '00:00:4????????'.

Click **Add**, and then click **OK** to exit the window.

This presents the call detail view with **Next & Prev** navigation button to navigate through records and find the calls matching the criteria as shown below.

Call ID	DevNo	TS	Call Status	Call Start Date & Time	Call Duration	Release C...
18	2	16	C laArR	2002-10-10 14:56:56.231125	00:00:42.686875	Normal call ...
19	2	16	A laA	2002-10-10 14:56:56.952625	00:00:41.965375	Normal call ...
20	2	16	A laA	2002-10-10 14:56:58.312125	00:00:40.600000	Normal call ...
21	2	16	A laA	2002-10-10 14:56:59.605250	00:00:39.300000	Normal call ...
22	2	16	A laA	2002-10-10 14:57:01.297625	00:00:37.620375	Normal call ...
23	2	16	A laA	2002-10-10 14:57:01.380250	00:00:37.537750	Normal call ...
24	2	16	A laA	2002-10-10 14:57:02.067750	00:00:36.850250	x00
25	2	16	A laA	2002-10-10 14:57:03.017750	00:00:01.060625	x00
26	2	16	A laA	2002-10-10 14:57:03.082250	00:00:35.835750	Normal call ...
27	2	16	A laA	2002-10-10 14:57:03.100250	00:00:35.815250	Normal call ...

Off-line Viewing | C:\Program Files\GL Communicatio | 503 Frames

Figure 76: Specify CDR criteria

7.6 Display Selected Call Summary

Select the desired call in the call trace view pane and select **Call Detail Record > Display Selected Call Summary** menu item to view the summary details of the specific call.

Also double click on the specific call in the call Detail Record view pane to view the summary of the selected call.

7.7 Display Entire Summary

Select **Call Detail Record > Display Entire Summary** menu item to view the entire summary of the calls.

7.8 Closing Call Detail Record

Call Detail Record can be closed form the **Call Detail Record > Close Call Detailed Record** menu item as shown in the figure below or by choosing **Close Call Trace View** option by right-clicking on call detail view.




Figure 77: Close Call Detailed Record

7.9 Export Trace File

Select **Call Detail Records > Export** menu item or right-click on the call detail view and choose **Export Call Trace Records** option to open the window as shown in the figure below to export the call details into a file. It exports the trace file details with extension name "cte" for subsequent import into a database or spreadsheet.




Figure 78: Export Trace File

(Intentional Blank Page)

Section 8.0 Protocol Analyzer Configuration

8.1 Analyzer GUI Options and Protocol Configurations

This window provides a consolidated interface for all the important GUI and Protocol settings required in the analyzer. This includes various options such as protocol selection, startup options, stream/interface selection, filter/search criteria and so on.

Select **Configure > Protocol and GUI** from the main menu, to open the screen as shown in the figure below.




Figure 79: Protocol and GUI option

Additionally, the user can save the configuration settings done in any of these options to a file or just revert back to the default values by using the following menu options:

Menu Options

Save: Select **Save** from the menu to save the configuration settings done in any of the options to a file with an extension ***.ACF** as shown in the figure below.




Figure 80: Save Configuration Options to File

Load: Select Load to load the previously saved *. ACF file from the location where this file was saved as shown in the figure below.




Figure 81: Load Configuration Options

Default: Click **Default** from the main menu to revert back to the default settings.

8.1.1 Selecting summary columns to display

For detail information on this refer to section Summary Column Selection.

8.1.2 Menu Checked Options

This lists the following two options

- Select **View Latest Frame > Packet** check box to display the latest frame in the summary view.
- Select **Enable Periodic Trace Saving** check box to save the settings of **Periodic File Saving Specification**.




Figure 82: Menu Checked Option

8.1.3 Protocol Standard Selection

This options is used to select the protocol decode standard. For more information on this refer to section Protocol Standard Selection.




Figure 83: Protocol Standard Selection

8.1.4 Network/User side Selection

Select User /Network Side selection to open the window as shown in the figure below. For more information on this refer to section [User/Network Side Specification](#).




Figure 84: Network/User side Selection

8.1.5 Time Format

Four time display formats are supported for both **Real-time** and **Offline** analysis. These time formats can be changed during both off-line and real-time analysis by selecting the required time format as shown in the figure below. For more information on **Time Format** refer to section [Time Displays](#).




Figure 85: Time Format


8.1.6 View Filter

This option is used to filter frames displayed in the Summary View. For more information on **View Filter** refer to section [Filtering Criteria](#).

8.1.7 View Search

This option is used to search the Summary View by decoded Summary column values. For more information on **View Search** refer to section [Setting Search Criteria](#).

8.1.8 TCP Connection Options

Protocol Analysis probes can run on multiple computers. They are designed to send protocol summary information and binary frame data via **TCP-IP** connection to a **Database Loader** to load data into a database. To set the TCP-IP parameters, select **TCP Connection Options** from the **Database** menu or click on  TCP Connection Options button from **Configure > Protocol and GUI Options** to open the window as shown in the figure below.




Figure 86: TCP Connection Options

In order to test the TCP/IP connection, the probe **IP address** and the **IP Port** name must be entered. Prerequisites for remote protocol analysis probes are following:

- Database installation and configuration
- Creating and configuring protocol table
- Database Loader installation and configuration

Probes can be configured to filter only subset of frames according to some criteria. For example, to load the database with complete information, all the three data types for exporting (loading into database), i.e., **frame octets**, **summary fields** and **status** information must be checked or the **send call details** records option must be checked. For detail information on this, refer to [GL's Net Surveyor™](#).

8.1.9 Periodic trace saving options

For detail information on periodic trace saving options refer to section [Periodic Trace Saving Options](#).

8.1.10 Startup Options

Startup option is used to enable the startup tasks such as Enable periodic trace saving, Activate Filter, Build Call detail records, Connect to a remote database via TCP/IP and Start real-time tracing.

Click on  Startup Options from **Configure > Protocol and GUI Options** to open the screen as shown below.




Figure 87: Startup Options

Load Options from File and Execute Tasks on Analyzer Startup

Check this option and click on browse button to browse the configuration file (*.acf) from the installation directory. This will load the options saved in the *.acf file on analyzer startup.

Include Physical Layer Alarms

Check this option to include alarm frequencies.

Capture Error Details

Check this option to capture details of frame errors.

Enable periodic trace saving

Enables periodic trace saving immediately when analyzer is opened. For more information on this refer to section [Periodic Trace Saving Options](#).

Activate Filter

Activates filter when analyzer is opened. For more information on this, refer to the section Activate Filter.

Build Call Detail Records

Activates Call Detail View when analyzer is opened. For more information, refer to [Build Call Detail Record](#).



Note:

This feature is not applicable to HDLC, MLPPP, and SaHDLC analyzers.

Connect to a remote database via TCP/IP



Note:

This feature is applicable to real-time analyzer only.

Connects to remote database loader when analyzer is opened. For more information on this refer to [Net Surveyor™](#)

Start real-time tracing

Select the **Start real-time tracing** check box and click **Execute** to start the real-time capturing. A warning message for overwriting the temporary trace file gets displayed. If you want to overwrite click **Yes**, else, click **No** and save it in a new file in the desired location. This new file replaces the default specified in the capturing options dialog. For more details refer to section [Start Real-time](#).

Open PDA

Check this option to invoke **Packet Data Analysis** application automatically at startup. For more information refer to the section PDA Startup Options.

8.1.10.1 Executing Tasks on Analyzer Startup

- Click on **Configure → Protocol and GUI Options**
- Click on **Select summary columns to display** option and select the summary columns to be displayed on analyzer startup. Refer to the figure below:




Figure 88: Selection of Summary Columns

- Click on **Startup Options** and select the required options to be executed on analyzer startup. Refer to the figure below:




Figure 89: Selection of Startup Options

- Click on **Save** to save in auto configuration file format. Refer to the figure below:




Figure 90: Saving Configuration File

- In the Startup Options check **'Load Options from File and Execute Tasks on Analyzer Startup'** option and click on browse button to browse and select the saved *.acf file. Refer to the figure below:




Figure 91: Loading Configuration File

- Close and restart protocol analyzer to automatically start with the startup tasks.

8.1.11 Data Link Groups (DLG)



Note:

Data Link Groups features are not applicable for HDLC, SaHDLC, GPRS Ga/Gn, ATM, UMTS, PPP, and TRAU Protocols

The data link groups help in defining the direction of the calls in a given network. It forms logical groups comprised of unidirectional (either 'Forward' or 'Backward') data links. This option is essential to configuring call detail records (CDR) where redundant signaling links can be used on different T1/E1 ports and time slots.

The direction is an essential part of the DLG specification because for many protocols like SS7, GSM etc. the CDR fields that are used to separate calls must be swapped depending on the direction.

All unidirectional data links are grouped under a single name. The name given to DLG is just a case sensitive string used to combine multiple data links in a single DLG.

To invoke a data link group option select **Configure > Protocol and GUI** from the main menu, and click Data Link Groups to open the screen as shown in the figure below.

Card	TS	Sc	Dir	Data Link Group Name
1	0	0	-->	West
2	1	1	<--	West
3	2	0	-->	West
4	3	1	<--	West
5	0	0	-->	East
6	1	1	<--	East
7	2	0	<--	East
8	3	1	-->	East

Figure 92: Data Link Groups

Data Link Group Specification:

One or more unidirectional links defined by card, timeslots and sub-channel selection.

Select cards, timeslots and sub-channels either directly by mouse or keyboard using extended window list box selection that includes the "shift" and "ctrl" keyboard keys for multiple extended selection or use "Odd Cards", "Even Cards", "All Cards", "None" push buttons to select or deselect cards.

Specify the same "Data Link Group Name" sting to combine multiple links in a DLG and also check "Forward Link Direction" for forward direction and uncheck for backward direction. The same DLG always has the same data link group name string.

After the specification has been made, click **Add** to add the selection to the list of DLGs that are displayed in the lower part of the pane.

Data Link Group Display pane

Displays the current DLG selection

- Some or all of the unidirectional links can be deleted from the current selection.
- "Delete Sel" button deletes the selected links from the current selection.
- "Delete All" button deletes all links from the current selection.
- "Default" button sets the default selection.

When the dialog is closed the current DLG selection is automatically activated.

The configuration in the above figure has two DLGs: "west" and "east". The "west" logical link (DLG) consists of four unidirectional links on cards (ports) 1, 3 in the forward direction and 2, 6 in the backward direction. The "east" logical link consists of two unidirectional data links: a forward link on card 5 and 8 and a backward link on card 6 and 7. The data link grouping is essentially a definition how to combine unidirectional data links in bidirectional logical links (DLGs) distinguished by their DLG Name.

8.1.12 View Font Size

This option allows the user to choose the relevant font size to view the Summary, Detail, Hex, Statistics, and Call Detail Records views. Select the option buttons with various font sizes such as Extra Large, Large, Normal, Small and Very small.




Figure 93: View Font Size

8.1.13 INI Decode Options




Note:

- Currently decode customization options through INI files features are not applicable for HDLC, GPRS, UMTS, GR303, V5.x, Frame Relay, and TRAU Protocols.
- For details on the INI decode customization options, refer to Appendix B

The .INI file configuration enables the user to customize the certain decode options and values in the INI file (located in installation directory) to get proper decodes.

INI file is like any other ASCII file such as '*.txt' file and hence can be edited easily in a Notepad®.

The same can be edited in the GUI as explained below:

Click  INI Decode Options from Configure > Protocol and GUI Options





Figure 94: INI Decode Option



Note:

- The # indicates the parameters that can be edited for proper decoding.
- If there are no parameters seen, then it means that no customization in decode options is allowed for this protocol analyzer

- Click **Edit INI** to open the editor as shown in the figure below:



```

[#PDU_ASSEMBLY]
PDU_ASSEMBLY_DLL_NAME.0="ProtCaptSS7SccpXudtAssembly.DLL"
PDU_ASSEMBLY_PARSE_LEN_VAL_FILTER_LIST.0="ALL LEN 32-4096"

; 0 - Disable PCR, 1 - Enable PCR
[#PREVENTIVE_CYCLIC_RETRANSMISSION]
PREVENTIVE_CYCLIC_RETRANSMISSION = 0 ;1

[#MAP_VERSION]
MAP_VERSION_VALUE = 99 ;4

[#INAP_VERSION]
INAP_CS_VERSION_VALUE = 1 ;2

[#CAMEL_VERSION]
CAMEL_VERSION_VALUE = 3 ;6

[#BTNR_PROTOCOL]
VALUE = 1

[#PROTOCOL_DECODE_ITU]
SSNCAP_MIN      = 146
SSNCAP_MAX      = 146
SSNMAP_MIN      = 5
SSNMAP_MAX      = 10
SSNINAP_MIN     = 12
SSNINAP_MAX     = 12

[#PROTOCOL_DECODE_ETSI]
SSNCAP_MIN      = 146
SSNCAP_MAX      = 146
SSNMAP_MIN      = 5
SSNMAP_MAX      = 10
SSNINAP_MIN     = 12
SSNINAP_MAX     = 12

[#PROTOCOL_DECODE_ANSI]
SSNIS41_MIN     = 6 ; MAP
SSNIS41_MAX     = 6 ; MAP
SSNCNAM_MIN     = 232 ; CNAM
SSNCNAM_MAX     = 232 ; CNAM
SSNTCAP_MIN     = 231 ; TCAP
SSNTCAP_MAX     = 231 ; TCAP
SSNCAP_MIN     = 146
SSNCAP_MAX     = 146
; If 0 - ISUP
; else - CNAME
[#SS7_CALLTRACE_SELECTION]
SS7_CALLTRACE_TYPE = 0

[#SS7_HIGH_SPEED_LINK_SELECTION]
HIGH_SPEED_LINK_SELECT = 0; 1

```

Figure 95: .INI File

- Once the decoding options are edited in Notepad®, **save** and **close** the window. Click **Ok** on the conformation window as shown in the figure below.
- Close and open the Protocol Analyzer to see the decode changes in the GUI.






Figure 96: Warning Message

 **Note:**
The changes will take effect when the protocol analyzer application is restarted.

8.1.14 Define Summary Columns

User can define the required summary columns through  **Define Summary Columns** option.

- 1) Select Configure **Menu** → **Protocol and GUI Options** → **Define Summary Columns**.
- 2) Expand the protocol layer and select the required field to display as shown in the figure below.




Figure 97: Define Summary Column

Expand

Click on **Expand** to make visible all layers of the selected protocol standard.

Collapse

Click on **Collapse** to close all the layers of the selected protocol standard.

Wildcard Search

User can search the required filters through wildcard search. For example **A*t** can search the filters which starts from 'A' and ends with 't' like **Act** or **Alphabet**. Click on **Prev** or **Next** to search the filter backward or forward.

- 3) Click on "Define" and a popup message will appear, refer to the figure below. Click on "OK".




Figure 98: Popup Message

- 4) Selected field is now visible in the "Select Summary Columns to Display".

5) Select the field from the Hidden Summary Column and click on "Display Selected Columns".




Figure 99: Adding the Summary Field to Display Summary Column

6) Selected field is now visible in the Analyzer. Refer to the figure below:

The screenshot shows the SS7 Protocol Analysis SS7 ITU software interface. The top window displays a table of captured frames with columns: Dev, TSlot, Frame#, TIME (...), Len, BSN, BIB, A bit, FSN, FIB, SLC, DPC, OPC, SCCP Message Ty..., and MAP R99 Package. The 'A bit' column is highlighted with a red box, showing values of 1 for frames 405, 408, 411, and 412. Below the table, the 'Card2 TimeSlot=16 Frame=405 at 00:00:54.413250 OK Len=81' is shown. The 'HDLC Frame Data + FCS' section displays the MTP2 and MTP3 layer details, including BSN, BIB, FSN, FIB, LI, Service Indicator, and Priority Code. The 'Hex Dump of the Frame Data' section shows the raw hexadecimal data of the frame.

Dev	TSlot	Frame#	TIME (...)	Len	BSN	BIB	A bit	FSN	FIB	SLC	DPC	OPC	SCCP Message Ty...	MAP R99 Package
✓ 2	16	405	00:00:...	81	0	1		58	1	14	4.15...	4.10...	UDT unidata	Begin
✓ 2	16	406	00:00:...	101	0	1		59	1	8	4.15...	4.10...	UDT unidata	Begin
✓ 2	16	407	00:00:...	259	1	1	1	60	1	0	4.15...	4.10...	UDT unidata	Continue
✓ 2	16	408	00:00:...	66	1	1		61	1	12	4.68.3	4.10...		
✓ 2	16	409	00:00:...	133	1	1		62	1	4	4.15...	4.10...	UDT unidata	Begin
✓ 2	16	410	00:00:...	193	6	1		63	1	0	4.15...	4.10...	UDT unidata	Begin
✓ 2	16	411	00:00:...	103	8	1		64	1	10	4.15...	4.10...	UDT unidata	Begin
✓ 2	16	412	00:00:...	208	8	1	1	65	1	0	4.15...	4.10...	UDT unidata	Continue

Figure 100: Added summary field



Note:

To remove the selected summary field, do the following:

1. **Select Configure Menu → Protocol and GUI Options → Define Summary Columns.**
2. Select the added summary field to be removed.
3. Click on 'Define'.

8.2 Capture Options



Note:

This feature is applicable to real-time analyzer only.

This provides various options such as trace file options, card and timeslot selections, real-time filter options, etc. For detail information on this, refer to [Capture Menu Features](#).

(Intentional Blank Page)

Section 9.0 Status Indicators

The analyzer has status indicators at the bottom of the window as shown in figure below:




Figure 101: Analyzer Status Indicators

9.1 Status and Progress Indicator

This is the first (leftmost) indicator that displays the following information:

- Bandwidth utilization (payload bytes (not counting flags) / total bytes (Frame bytes plus flags) during real-time capturing.
- Real-time or off-line mode.
- Real-time capturing status (Running or stopped).
- Notification when a long process is in progress, for example, trace is exported, statistics are recalculated etc. when the user interface is temporary disabled and the hourglass is being displayed.
- Notification that filtering is active.



Note:

Status and progress information is obtained for Real-time Analyzer Only.

9.2 Trace File Name

The second indicator displays the trace file name.

9.3 Filtered and Total Frame Count

The third indicator displays filtered and total frame count when the filtering is active and just the total frame count when filter is deactivated.

9.4 Error Counters

The fourth indicator is blank when no errors are encountered. Separated counts are displayed for cyclic redundancy check and framing errors. When there is more number of error counters click **View** → **View Capture Error Details** to extend the error counters in the status bar to display all types of errors such as CRC, Frame Error, Reassembly, Dropped, Missing, and Duplicate error counts.

(Intentional Blank Page)

Application II - Remote / Offline Analyzer

Section 1.0 Installation

GL's offline/remote protocol analyzers are available as optional software. Functionally, they are similar to real-time protocol analyzers that are integrated with T1E1 Analyzers.

With Remote Protocol Analyzer applications, users can perform real-time as well as offline protocol analysis from any remote-site.

For installing offline and remote protocol analyzers, first install T1 E1 hardware, server software, and HDLC capture software. At the remote site, install the GUI based Offline/Remote protocol analyzer application. For details on installing T1E1 Analyzer, refer to [T1E1 Installation User Manual](#) for the required Windows® operating system.

1.1 Installation Procedure

The installation procedure for offline/remote protocol analyzer is as follows.

- Dongle Installation
- Software Installation

1.2 Dongle License Installation

Dongle is a hardware lock, which is installed before installing analyzer software. Each dongle has a number uniquely associated with it. To install the dongle hardware and corresponding license, follow the steps below:

- Double-click the **setup.exe** file in the dongle license installer directory to initiate the install-shield wizard. Dongle installs the application license
- Click **Finish** in the installation wizard to complete the license installation as shown in the figure below:




Figure 102: Dongle License Installation

1.3 Software Installation (Windows® XP)

- Double-click the executable in the GL’s Remote protocol analyzer installation CD to open the installation shield wizard as shown in the figure below:




Figure 103: Welcome Screen

- Click **Next** in the above wizard, and click 'Yes' to accept the license agreement as shown in the figure below:




Figure 104: License Agreement

- Select the destination folder to install. The default destination folder is set to **\Program Files\GL Communications Inc.\Protocol Analyzer**.




Figure 105: Choose Destination Folder

- In the **Select Program Folder** dialog, click **Next** to add the program icons to the default folder. (This sub-menu will be added to the **Start** menu). To change the name of the folder, type the new name, and then click **Next**.




Figure 106: Select Program Folder

- Status of Installation process is displayed as shown in the figure below:




Figure 107: Setup Status

- Click **Finish** to complete the installation of the software.




Figure 108: Protocol Analyzer Installation Completed

Warning: If the user invokes offline/remote analyzer software without installing dongle license, the following message is displayed.




Figure 109: License Error Message

Section 2.0 Getting Started with Remote Protocol Analyzer

2.1 Invoking Remote Protocol Analyzer

For HDLC based protocols, HDLC frames can be transported via TCP / IP and captured remotely with a GUI Protocol Analyzer Client. At the client location the full capability of a real-time Protocol Analyzer is available for storing, analyzing, filtering, displaying, and processing the protocol information.


Double click the Remote Protocol Analyzer icon  located on the desktop to invoke the application as shown in the figure below. The remote protocol analyzer is located in the directory **\Program Files\GL Communications**.



Figure 110: Invoking the Remote Protocol Analysis Application

2.1.1 Remote Analysis

Click on **Remote Analysis** button to invoke **WCS Server Connect** dialog. Remote Analyzer requires users to connect to a remote system that consists of GL's T1/E1 cards running in server mode.




Figure 111: WCS Server Connect

Click **Remote Analysis** to open the **WCS Server Connect** screen as shown in the figure below. User can connect to the server by entering the **IP Address** and the **IP Port** in the respective fields.

Note: To connect to T1 cards, select the ports number as 17080, and to connect to E1 cards, select the ports number as 17090.

Add: Click **Add** to add an IP address to the **Connected Servers** list. You can add multiple Server IP Addresses to connect simultaneously to all T1E1 cards.

In order to connect a remote analyzer to the server, select the IP address from the Connected Servers pane and click **OK**.

Delete: To delete an already added IP address, select the IP address to be deleted from the Connected Servers pane and click **Delete**.

IP Address: Enter an IP address of server in this field, which is used to perform the real time analysis.

IP Port: Enter the IP Port of the server depending on the T1/E1 card used. If connecting to a server, which has T1 card in it, then the IP Port will be 17080. If connecting to a server, which has E1 card in it, then the IP Port will be 17090.

Connected Servers: In this pane, all the IP addresses and the IP port numbers are added and listed. User can select the IP address of the server and click Ok to connect to the server. Click Cancel to cancel the connection from the server.

2.2 Stream /Interface Selection

The **Stream /Interface Selection** dialog allows a user to specify ports for monitoring, and user/network side capture. To open the **Stream /Interface Selection**, follow the steps below:

- Select the **Capture > Stream/Interface Selection** or
- Click **Stream/Interface**  from the toolbar

The figure below shows the timeslots selection of a remote analyzer that is connected to two T1E1 Analyzers, each having a dual card. In such cases the remote analyzer displays all four cards under the Port and Time Slot Selection pane. This allows simultaneous connection to multiple T1/E1 using single remote client GUI and enables monitoring two or more cards instantaneously.




Figure 112: Specifying timeslot Selection for a Remote Analyzer

Port and Timeslots Selection

The time-slot selection dialog allows user to specify devices and corresponding time slots on which the data is being captured.

For T1, all (0-23) or required timeslots may be selected.

While for E1 systems, excluding timeslots 0 and 16 (for CAS signaling only), all or the required timeslots may be selected.

Data Transmission Rate

Selection of the data transmission rate in various modes like single channel, sub channels, or hyper-channels is possible.

Single Channel

If all eight bits in a byte are used for data transmission, then this is referred to as **64 kbps** format. If only seven bits out of eight are used for data transmission, then this is referred to as **56 kbps** format.

Hyper Channel

Multiple channels may be defined per card.

Nx64 Kbps: This indicates selection of multiple timeslots (contiguous or non-contiguous) each of 64 Kbps




Nx56 Kbps (Bits 1-7): This indicates selection of multiple timeslots (contiguous) of each 56 Kbps with bits selected (1-7)



Nx56 Kbps (Bits 2-8): This indicates selection of multiple timeslots (contiguous) of each 56 Kbps with bits selected (2-8)

Sub channel

In addition, the data may be transmitted on any of the user-defined bits (contiguous only), in which case, the user must select one of the options and its corresponding DS0 bits under **Subchannels 8-56 kbps** pane. The actual sub channels comprising a lower bandwidth pipe are selected using the subchannel selection list box.

Depending on data transmission rate, the number of subchannels can be selected according to the table below. Each pipe 8 - 56 kbps can be comprised only from the contiguous subchannels. For example for 32 kbps pipe the following sub channel selections are valid 1-4,2-5, 3-6, 4-7. On the other hand, selecting subchannels 1, 2, 4 and 5 for 32 kbps is invalid: the total bandwidth is 32 kbps for these four selected subchannels, however they are not contiguous.

Subchannel Rate	Subchannels per Time Slot	Example	Example Explanation
8	1,2,3,4,5,6,7,8		Three Independent pipes are specified: 1-2, 4 and 6. Each is 8 kbps
16	1,2,3,4		Two pipes 16 kbps each are specified. These two pipes are 1-2 & 3-4
24	1,2		Two pipes 24 kbps each are specified. First pipe 1-3 subchannels, second 6-8 subchannels

32	1,2		Two 32kbps pipes take entire DS0. First one 1-4 subchannels, second 5-8 subchannels
40	1		One pipe 40 kbps takes subchannels 1-5.
48	1	Similar to 40 kbps but 6 consecutive subchannels must be selected	
56	1	Similar to 40 kbps but 7 consecutive subchannels must be selected	

IP Addr / Cards: Click IP Addr / Cards to see the IP addresses of the servers connected and the corresponding card numbers as shown in the figure below.




Figure 113: Info of IP Addr/Cards

Example Operation:

To Playback an *.HDL file on the server & capture it on the remote analyzer, follow the steps as shown below:

- 7) Invoke the **T1/E1** analyzer application on the remote server, and start the server.
- 8) Invoke the **Remote analyzer** application and click on **Remote Analysis**.
- 9) Enter the **IP Address** and the **IP Port** of the server and click **Add**.
- 10) Select the added **IP address** from the **Connected Server** pane and click **OK**.
- 11) At the Server side, invoke the **HDLC Playback** application and playback an *.HDL file on card #1, timeslot 1, 2.
- 12) On the remote analyzer open the stream interface selection and select the opposite card that is card #2 and timeslots 1, 2.
- 13) Start the real-time analysis on the remote analyzer to capture the frames.

Note: Select All timeslots if the channel selection is not known.

2.3 Setting Capture Filter

Select **Capture > Capture Filter** option to directly exclude **LSSU** (Link Status Signal Unit), **FISU** (Fill-in Signal Unit) frames or any other user-defined frames. **LSSU** frames (of length 5) communicate information about the signaling link between the nodes on either end of the link. **FISU** frames (of length 7) support the monitoring of link traffic because they undergo error checking

For example, to exclude frames of length 5, enter and **click OK** as shown in the following figure. Frames of length 5 will be excluded during real-time capture.

If frames are of length other than 5 and 7, users need to enter the command as in the following examples:

If all the frames between 16 and 20 are to be captured enter ALL LEN 16-20.




Figure 114: Capture Filter using Remote Analyzer

Note: Capture Filter settings should be done before real time capturing is started.

2.4 Start Real-time Analysis

Refer to section [Start Real-time](#) for complete details.

Section 3.0 Getting Started with Offline Protocol Analyzer

Click **Offline Analysis** to open the interface in offline analysis mode. This mode allows you to analyze the pre-captured *.hdl files. To open the trace for **Offline Analysis**, follow the steps given below:

- Click **File > Off-line** as shown in the figure below Or
- Click **Off line from a File**  from the tool bar




Figure 115: Open a Trace from a File for Off-line Analysis

The GUI appears as shown below:




Figure 116 : Offline Analysis

(Intentional Blank Page)

Appendix A - Glossary

- **Device Number (one relative)** -It displays the device number on which the data is being captured.
- **Time Slots-** This field displays range of selected timeslots.
- **Sub Channels** - This field displays subchannel number if any selected.
- **Frame Number (zero relative)** - This represents the unique number assigned to each frame in the order in which it was captured. Frame numbers can be any non-negative numbers and is limited only by the number of frames captured to the trace file.
- **Time** - This field displays the time as configured by the user in **View > Time Format**. For more information refer to [Time Displays](#).
- **Frame Length (Including 16 bit FCS)** - This field displays the length of each captured frame.
- **OK Frames Only** - Filters all frames that are error free.
- **Frame Error Status-** This field displays various error messages during capturing /decoding such as Frame error, Decode error, FCS error, and so on.

SS7 ITU/ ETSI/CHINA/UK Standard:

- **BSN/FSN (Backward/Forward Sequence Number)** - This field displays BSN and FSN, (each of length 7-bit), which are used to acknowledge the message signal units from the remote end of the signaling link.
- **BIB/FIB (Backward/Forward Indicator Bit)** - This field displays BIB and FIB, (each of length 8-bit) which are used in the basic error control and acknowledgement functions.
- **Status Field-** Status field in LSSU frames is an 8/16-bit field that indicates initiation of link alignment, quality of received traffic, and status of processors at either end of the link.
- **SLC (Signaling Link Code)** - SLC Link code is a 4-bit code that identifies the link set carrying SS7 signaling information. The range of SLC is 0-15. For example, enter SLC value 23, as shown in the figure below to filter the frames that have the value as 23.
- **DPC (Destination Point Code)** - This field displays the DPC value that represents a numeric address used to uniquely identify the receiving signalling point.
- **OPC (Originating Point Code)** - This field displays the OPC value that represents a numeric address used to uniquely identify the sending signaling point. This column shows the originating point code value.
- **SCCP Message Type (Signaling Connection Control Part)** - This field displays the SCCP that uses **subsystem numbers (SSN)** and various **message types** to allow messages to be addressed to specific applications (called **subsystems**) at each signaling points.
- **SSN** - This field displays the SSN that is used to identify the specific applications (called **subsystems**) at each signaling points.
- **MAP (Mobile Application Part) Package and Component Type** - MAP is a protocol that enables real-time communication between nodes in a mobile cellular network. It encapsulates package and components types of Transaction Capabilities Application Part (TCAP) messages over a common channel network.
- **MAP Operation and MAP Error (Mobile Application Part (Error and operation)** - This field displays the processes that are required to invoke a MAP operation at remote node and the corresponding errors that are returned by MAP error.
- **INAP (Intelligent Network Application Part) Package and Component Type** - INAP is a protocol that enables real-time communication between intelligent network elements. It uses basic TCAP services and is based on various TCAP package like Begin, Unidirectional, continue and so on. It also includes various TCAP components such as Invoke the operation, Return the results of an operation i.e. success /failure etc.
- **INAP Operation Code and Error Code** - This field displays a list of INAP operations at remote node and the corresponding errors that are returned.
- **CAP (CAMEL Application Part) Package and Component** - CAP is a protocol that supports the information flows between CAMEL (Customized Application for Mobile network Enhanced Logic) functional elements. It uses basic TCAP Services and is based on various TCAP package like begin, unidirectional, continue and so on. It also includes various TCAP components such as Invoke the operation, Return the results of an operation i.e. success /failure etc.

- **CAP Error** - This field displays a failure code for the invoked CAP operation.
- **CIC (Circuit Identity Code) (ISUP/BTUP)**- This is an 8bit field within the (Service Information Field) of the ISUP (ISDN User Part) message, which identifies the links that carry user traffic.
- **ISUP (ISDN User Part of SS7) Message Type** - This field displays the ISUP message that indicates the establishment/release of SS7 call and maintenance of the call.
- **Called No** - This displays the destination number.
- **Calling No** - This displays the caller related messages.
- **Transf/ConnRedirr#** - This field represents either called party or call forwarded number.
- **Reg Test Message** - This field displays the test messages sent across the link to test the integrity of the link.
- **Net Mgmt Message** - This field displays the network starting that is used to manage from maintaining active link/ standby link, decide when the link should be down/up etc.
- **BICC Msg Type:** This field displays the BICC (Bearer Independent Call Control) message type code that uniquely defines the function and format of each ISDN User Part message. The message types include Address complete, Answer, Call Progress, Connect, Continuity and so on.
- **Msg Type:** The B-ISDN User Part (B-ISUP) is applicable to international B-ISDN networks. This field displays the message type such as Address Complete, Blocking, Answer, and so on.
- **Interconnect User Part (IUP /BTUP) Layer** - This layer includes call signaling messages required to establish, maintain & release of SS7 call between SS7 nodes. It is equivalent to ISUP in SS7 UK standard
- **Reg Testing Messages** - These Messages are used for checking the integrity of the link. A given pattern of octets is sent in SLTM message and if the same pattern is received in the SLTM Ack, the link functions properly.
- **NMPC** - "Destination Point Code" in Network Management Message.

SS7 ANSI Standard:

- **Component Type** - This field displays the component types in BER notation (TCAP ANSI) such as Invoke, ReturnResult, ReturnError, Reject, invokeNotLast, and ReturnResult.
- **SLS (Signaling Link Selection)** - This field displays the 8-bit SLS value that is normally used for load sharing across signaling links.
- **TCAP Package Type** - Transactional Capabilities application part (TCAP) supports the exchange of non-circuit related data between the applications across the SS7 network, using the SCCP connectionless service as a transport. Queries and Responses sent between SSP's and SCP's are carried in TCAP messages. In mobile networks (IS-41 and GSM), TCAP carries mobile application part (MAP) messages sent between mobile switches and databases to support user authentication, equipment identification and roaming.
- **CNAM Package Type** - Calling Name Delivery allows the name of the calling party to be delivered to the called party. CNAM is an optional feature allowing the CPE connected to a switching system to receive calling party's name.

Appendix B - Configuring SS7Prot.ini file




Figure 117: INI Decode Option for SS7 Analyzer

- INI file configuration enables user-defined SSN values to be set for INAP, IS41, and CAP decoding in the SS7Prot.ini file (located in Program Files\GL Communication Inc).
- **In SS7** protocol analyzer, INAP, MAP, and CAP are branched from SCCP layer and depend on the SSN value present in the called party number. Usually, these are decoded based on SSN value. Hence GL's SS7 analyzer provides the .INI file option enabling the user to enter any SSN value for INAP, CAP, and MAP decoding.
- **[#PROTOCOL_DECODE_ITU]** – This parameter allows users to set INAP, CAP and MAP values for ITU decoding standards.

SSNINAP_MAX , SSNINAP_MIN = 12 – This parameter gives maximum and minimum SSN value for INAP

SSNCAP_MAX, SSNCAP_MIN = 146 – This parameter gives maximum and minimum SSN value for CAP

SSNMAP_MAX, SSNMAP_MIN = 147 – This parameter gives maximum and minimum SSN value for GSM MAP

- **[#PROTOCOL_DECODE_ETSI]** – This gives SSN value to set INAP , CAP and MAP value for ETSI decoding standard.

SSNINAP_MAX , SSNINAP_MIN = 12 – This parameter gives maximum and minimum SSN value for INAP

SSNCAP_MAX, SSNCAP_MIN = 146 – This parameter gives maximum and minimum SSN value for CAMEL

SSNMAP_MAX, SSNMAP_MIN = 147 – This parameter gives maximum and minimum SSN value for GSM MAP

SSNINAP_MIN = 12 – This parameter gives minimum value SSN for INAP.

- **[#PROTOCOL_DECODE_ANSI]** – This header allows users to set the maximum and minimum values for TCAP and IS41.

SSNIS41_MAX, SSN IS41_MIN = 6 ; This gives maximum and minimum value of SSN for ANSI MAP.

SSNCNAM_MAX, SSNCNAM_MIN = 232 ; CNAM– This gives maximum and minimum value of SSN for CNAM.

SSNTCAP_MAX, SSNTCAP_MIN = 231 ; TCAP– This gives maximum and minimum value of SSN for TCAP.

SSNCAP_MAX, SSNCAP_MIN = 146– CAMEL – This gives maximum and minimum value of SSN for CAP.

Other values can also be customized as follows:

- **[#PDU_ASSEMBLY]** – This identifier gives the related information for PDU assembly.

PDU_ASSEMBLY_DLL_NAME

PDU_ASSEMBLY_PARSE_LEN_VAL_FILTER_LIST.0

- **[#PREVENTIVE_CYCLIC_RETRANSMISSION]** – If it is set to 'one' Retransmitted messages are excluded from CDR

PREVENTIVE_CYCLIC_RETRANSMISSION = 0;1

- **[#MAP_VERSION]** – This identifier gives the Map Version value.

MAP_VERSION_VALUE - This parameter is used to select MAP R99 or MAP R4 CS1 layer for decoding. If it is set to 99, then MAP R99 layer will be decoded, and MAP R4 layer will be decoded if the value is set to 4.

- **[#INAP_VERSION]** – This identifier gives the INAP Version value.

INAP_CS_VERSION_VALUE - This parameter is used to select INAP CS1 or INAP CS2 layer for decoding. If it is set to 1, then INAP CS1 layer will be decoded, and INAP CS2 layer will be decoded if the value is set to 2.

- The following figure shows the INAP layer being decoded when the INAP version value is set to 1.




Figure 118 : Decode of INAP CS1 Layer

- When **INAP_CS_VERSION_VALUE** is set to 2, the INAP decoding depends on the type of the protocol standard selected. If SS7 ITU standard is selected, the INAP CS2 ITU layer gets decoded as shown below.

The figure consists of two main screenshots. The top screenshot shows the SS7Prot.ini file in Notepad. The configuration includes sections for PDU Assembly, Preventive Cyclical Retransmission, MAP Version, INAP Version, CAMEL Version, and BTNR Protocol. The INAP CS2 ITU layer is highlighted with a red box, and a blue annotation explains that INAP_CS_VERSION_VALUE = 1 is commented, so the value of 2 is used.

```

[ #PDU_ASSEMBLY ]
PDU_ASSEMBLY_DLL_NAME.0="ProtCaptSS7SccpXudtAssembly.DLL"
PDU_ASSEMBLY_PARSE_LEN_VAL_FILTER_LIST.0="ALL LEN 32-4096"
; 0 - Disable PCR, 1 - Enable PCR
[ #PREVENTIVE_CYCLIC_RETRANSMISSION ]
PREVENTIVE_CYCLIC_RETRANSMISSION = 0 ;1

[ #MAP_VERSION ]
MAP_VERSION_VALUE = 99 ;4

[ #INAP_VERSION ]
INAP_CS_VERSION_VALUE = 2 ;1
INAP_CS_VERSION_VALUE = 1 is commented
Hence, INAP_CS_VERSION_VALUE = 2 will be considered

[ #CAMEL_VERSION ]
CAMEL_VERSION_VALUE = 3 ;6

[ #BTNR_PROTOCOL ]
VALUE = 1
    
```

The bottom screenshot shows the SS7 Protocol Analysis SS7 ITU interface. It displays a table of protocol analysis results and a section for Optional Variable Length Parameters. The INAP CS2 ITU Layer parameters are highlighted with a red box, and a small Notepad window shows the configuration file being used for the analysis.

Dev	TSlot	Frame#	TIME (Relative)	Len	BSN	BIB	FSN	FIB	INAP CS2 Component Type	INAP CS2 Operation Code	INAP I
✓ 2	1	0	00:00:00.000000	78	1	0	2	0	Invoke	Initiate Call Attempt	
✓ 2	1	1	00:00:00.022250	53	1	0	2	0	Invoke	Release Call	
✓ 2	1	2	00:00:00.041375	78	1	0	2	0	Invoke	Initiate Call Attempt	
✓ 2	1	3	00:00:00.063625	97	1	0	2	0	Invoke	Connect	
✓ 2	1	4	00:00:00.088250	72	1	0	2	0			
✓ 2	1	5	00:00:00.109750	60	1	0	2	0	Invoke	Event Report BCSM	
✓ 2	1	6	00:00:00.129750	53	1	0	2	0	Invoke	Release Call	
✓ 2	1	7	00:00:00.149000	53	1	0	2	0	Invoke	Release Call	

Optional Variable Length Parameters = None
===== INAP CS2 ITU Layer =====
INAP CS2 Package Type = CHOICE
Begin = TAG 01100010 APPL CONST (IMPLICIT SEQUENCE)
Length = 45 (x2D)
Originating Transaction ID = TAG 01001000 APPL PRIM Tag
Length = 4 (x04)
Originating ID Value = x14670500
ComponentPortion = TAG 01101100 APPL CONST (IMPLICIT SEQUENCE OF)
Length =
Component =
Invoke =
Length =
InvokeID =
Length =
Value =
Operation Code =
Local Operation Code =

```

Edit INI C:\Program Files\GL Communications Inc\Probe E1 Analyzer\SS7Prot.ini

PDU_ASSEMBLY_DLL_NAME.0="ProtCaptSS7SccpXudtAssembly.DLL"
PDU_ASSEMBLY_PARSE_LEN_VAL_FILTER_LIST.0="ALL LEN 32-4096"
[ #PREVENTIVE_CYCLIC_RETRANSMISSION ]
PREVENTIVE_CYCLIC_RETRANSMISSION=0 ;1
[ #MAP_VERSION ]
MAP_VERSION_VALUE=99 ;4
[ #INAP_VERSION ]
INAP_CS_VERSION_VALUE=2 ;1
[ #CAMEL_VERSION ]
CAMEL_VERSION_VALUE=3 ;6
[ #BTNR_PROTOCOL ]
VALUE=1
[ #PROTOCOL_DECODE_ITU ]
SSNCAP_MIN=146
SSNCAP_MAX=146
SSNMAP_MIN=5
    
```

Figure 119 : Decode of INAP CS2 ITU Layer

- If SS7 ETSI standard is selected, the INAP CS2 ETSI layer gets decoded as shown below.

The screenshot shows the SS7 Protocol Analysis SS7 ETSI application. The 'Protocol standard selection' menu is open, with 'SS7 ETSI' selected. Below it, a table of captured packets is visible. The bottom pane shows the configuration for the INAP CS2 ETSI Layer, with several parameters highlighted in red boxes:

- `Optional Variable Length Parameters` = None
- `INAP CS2 ETSI Layer` = CHOICE
- `INAP CS2 Package Type` = TAG 01100010 APPL CONST (IMPLICIT SEQUENCE)
- `Begin` = 45 (x2D)
- `Length` = 4
- `Originating Transaction ID` = x:
- `Length` = 3
- `Originating ID Value` = T:
- `ComponentPortion` = C:
- `Length` = 3
- `Component` = T:
- `Invoke` = T:
- `Length` = 35
- `invokeID` = T:
- `Length` = 1
- `Value` = 0
- `Operation Code` = C:
- `Local Operation Code` = T:


Additional configuration parameters shown in the bottom pane include:

- `PDU_ASSEMBLY_DLL_NAME.0="ProtCapSS7ScpXudtAssembly.DLL"`
- `PDU_ASSEMBLY_PARSE_LEN_VAL_FILTER_LIST.0="ALL LEN 32-4096"`
- `[#PREVENTIVE_CYCLIC_RETRANSMISSION]`
- `PREVENTIVE_CYCLIC_RETRANSMISSION=0;1`
- `[#MAP_VERSION]`
- `MAP_VERSION_VALUE=99;4`
- `[#INAP_VERSION]`
- `INAP_CS_VERSION_VALUE=2;1`
- `[#CAMEL_VERSION]`
- `CAMEL_VERSION_VALUE=3;6`
- `[#BTNR_PROTOCOL]`
- `VALUE=1`
- `[#PROTOCOL_DECODE_ITU]`
- `SSNCAP_MIN=146`
- `SSNCAP_MAX=146`
- `SSNMAP_MIN=5`

Figure 120 : Decode of INAP CS2 ETSI Layer

- `[#CAMEL_VERSION]` – This identifier gives the CAMEL Version value.
- `CAMEL_VERSION_VALUE` - This parameter is used to select **CAMEL** Rel6 or CAMEL Rel3 layer for decoding. If it is set to 6, then CAMEL Rel6 layer will be decoded and CAMEL Rel3 layer will be decoded if the value is set to 4.
- `[#BTNR_PROTOCOL]` – **This identifier allows users to select TUP or IUP protocols for decoding.**
- `VALUE` - This parameter is used to select TUP or IUP (BTNR) for decoding. If it is set to 1, then IUP (BTNR) will be decoded, else TUP will be decoded.

- In addition, INI file can also be set to select the default summary fields for Surveillance (TCP/IP). Click EditINI button and edit as follows:

-  **Note:**
The TCP_CONNECT_SUMMARY_SELECT_DEFAULT selection is not visible in INI decode option window due to the presence of '\$' before the parameter.

<pre>[TCP_CONNECT_SUMMARY_SELECT_DEFAULT] DEFAULT_SUM_COL_INDEX.0=0 DEFAULT_SUM_COL_INDEX.1=1 DEFAULT_SUM_COL_INDEX.2=2 DEFAULT_SUM_COL_INDEX.3=3 DEFAULT_SUM_COL_INDEX.4=4 DEFAULT_SUM_COL_INDEX.5=5 DEFAULT_SUM_COL_INDEX.6=6 DEFAULT_SUM_COL_INDEX.7=11 DEFAULT_SUM_COL_INDEX.8=12 DEFAULT_SUM_COL_INDEX.9=13 DEFAULT_SUM_COL_INDEX.10=14</pre>	<pre>DEFAULT_SUM_COL_INDEX.11=15 DEFAULT_SUM_COL_INDEX.12=16 DEFAULT_SUM_COL_INDEX.13=17 DEFAULT_SUM_COL_INDEX.14=18 DEFAULT_SUM_COL_INDEX.15=23 DEFAULT_SUM_COL_INDEX.16=24 DEFAULT_SUM_COL_INDEX.17=25 DEFAULT_SUM_COL_INDEX.18=26 DEFAULT_SUM_COL_INDEX.19=27 DEFAULT_SUM_COL_INDEX.20=37 DEFAULT_SUM_COL_INDEX.21=38 DEFAULT_SUM_COL_INDEX.22=39</pre>
--	--

This allows Analyzer to auto-select the columns on clicking **Default** in the configuration window as shown in the figure below:




Figure 121 : Selection of Default Summary Fields for Surveillance (TCP/IP)

- [#SS7_CALLTRACE_SELECTION]** – This option will decode CNAM call detail records. To enable this option user has to select protocol standard as 'SS7 ANSI' and change 'SS7_CALLTRACE_TYPE' value as 2 i.e., SS7_CALLTRACE_TYPE = 2. to build CNAM call detail records.

```

SS7Prot.ini - Notepad
File Edit Format View Help

[PROTOCOL_DECODE_ANSI]
SSNIS41_MIN = 6 ; MAP
SSNIS41_MAX = 6 ; MAP
SSNCNAM_MIN = 232 ; CNAM
SSNCNAM_MAX = 232 ; CNAM
SSNTCAP_MIN = 231 ; TCAP
SSNTCAP_MAX = 231 ; TCAP
SSNCAP_MIN = 146
SSNCAP_MAX = 146

; If 0 - ISUP
; else - CNAME
[#SS7_CALLTRACE_SELECTION]
SS7_CALLTRACE_TYPE = 2

[#SS7_HIGH_SPEED_LINK_SELECTION]
HIGH_SPEED_LINK_SELECT = 0; 1

[DEF_SUM_Physical Link.0]
[DEF_SUM_MTP2.0]
    
```

The screenshot displays the SS7 Protocol Analysis SS7 ANSI application. The top window shows a table of call records with columns for Dev, TSlot, SubCh, Frame#, TIME (Relative), Len, Error, BSN, BIB, FSN, FIB, Status Field, and D. Below this, a detailed view of a CNAM layer packet is shown, listing various fields like TCAP Package, Response, Length, Responding Transaction ID, etc. At the bottom, another table lists call details including Call ID, Call Status, Call Start Date & Time, Call Duration, DevNo, TS, OPC, DPC, and Call Type.

Dev	TSlot	SubCh	Frame#	TIME (Relative)	Len	Error	BSN	BIB	FSN	FIB	Status Field	D
✓ 1	2	1-7	0	00:00:00.000000	63		88	1	46	1		2
✓ 2	3	1-7	1	00:00:00.001428	70		65	1	35	0		2
✓ 4	6	1-7	2	00:00:00.001571	63		120	1	80	1		1
✓ 1	8	1-7	3	00:00:00.002857	63		26	0	62	1		2
✓ 4	3	1-7	4	00:00:00.003285	63		36	1	14	1		2
✓ 4	2	1-7	5	00:00:00.004428	63		71	1	29	1		2
✓ 3	10	1-7	6	00:00:00.006285	70		55	1	49	1		2


```


===== CNAM Layer =====
001A TCAP Package = CHOICE
001A Response = TAG 11100100 PRIV CONST (IMPLICIT SEQUENCE)
001B Length = 33 (x21)
001C Responding Transaction ID = TAG 11000111 PRIV PRIM Tag
001D Length = 4 (x04)
001E Responding ID Value = 489 (x000001E9)
0022 Component Portion = TAG 11101000 PRIV CONST (IMPLICIT SEQUENCE)
0023 Length = 25 (x19)
0024 Component Type = CHOICE
0024 Return Result Last = TAG 11101010 PRIV CONST (IMPLICIT SEQUENCE)
0025 Length = 23 (x17)
0026 ComponentId = TAG 11001111 PRIV PRIM Tag
0027 Length = 1 (x01)
0028 Component IDs = x01
    
```

Call ID	Call Status	Call Start Date & Time	Call Duration	DevNo	TS	OPC	DPC	Call Type
0	Completed	2011-06-03 14:52:04.844571	00:00:00.057857	2	3	235....	2.16....	Query
1	Completed	2011-06-03 14:52:04.849428	00:00:00.063571	3	10	235....	2.16....	Query
2	Completed	2011-06-03 14:52:04.852571	00:00:00.091857	3	3	235....	2.16....	Query
3	Completed	2011-06-03 14:52:04.859285	00:00:00.077000	2	8	235....	2.16....	Query
4	Completed	2011-06-03 14:52:04.860571	00:00:00.077571	2	3	235....	2.16....	Query
5	Completed	2011-06-03 14:52:04.875142	00:00:00.089714	3	4	235....	2.16....	Query
6	Completed	2011-06-03 14:52:04.875285	00:00:00.064000	3	9	235....	2.16....	Query
7	Completed	2011-06-03 14:52:04.879714	00:00:00.063571	2	5	235....	2.16....	Query

Figure 122 : CNAM Call Detail Records

[#SS7_HIGH_SPEED_LINK_SELECTION] – This option will make the decode the SS7 links at higher signaling capacity SS7 links (1.536 and 1.984 Mbit/s, simply referred to as the 1.5 Mbit/s and 2.0 Mbit/s rates) are called High Speed Links. High speed links utilize the entire bandwidth of a T1 (1.536 Mbit/s) or E1 (1.984 Mbit/s) transmission facility for the transport of SS7 signaling messages. These rates can be used as a national optional.

In the **SS7Prot.ini**, if the user sets the '**HIGH_SPEED_LINK_SELECT**' value to 0, then MTP2 is decoded as low speed link.



- If **HIGH_SPEED_LINK_SELECT** is set to 1 then MTP2 is decoded as High Speed Link.




Figure 123 : MTP2 Decoded in High Speed Link